

Exploring Boltzmann-Factor Distributions of Precipitation-Nuclei in the TEM

Jamie Daugherty, P Fraundorf, David Osborn, Jai Kasthuri

► To cite this version:

Jamie Daugherty, P Fraundorf, David Osborn, Jai Kasthuri. Exploring Boltzmann-Factor Distributions of Precipitation-Nuclei in the TEM. Microscopy and Microanalysis 2016 meeting, Jul 2016, Columbus, Ohio, United States. pp.942-943. hal-01367881

HAL Id: hal-01367881 https://hal.science/hal-01367881v1

Submitted on 16 Sep 2016

HAL is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers. L'archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d'enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.

Exploring Boltzmann-Factor Distributions of Precipitation-Nuclei in the TEM.

Jamie Daugherty, P. Fraundorf,* and David Osborn Physics & Astronomy/Center for NanoScience, U. Missouri-StL (63121)

> Jai Kasthuri SunEdison, Inc., Maryland Heights, MO 63043, USA (Dated: September 16, 2016)

For nucleation in the solid-state, modern electron microscopes may allow one to examine precritical cluster distributions down to the size-scale of a single misplaced atom. A very specific challenge of this sort arises in the gigascale silicon integrated-circuit device industry, surrounding the important roles that oxygen in Czochralski silicon can play. We indicate here in particular that the number densities and sizes of precritical SiOx clusters in as-grown wafers, as estimated by elementary means, should be possible to quantify with modern techniques, provided that challenges associated with surface noise and thickness estimation can be overcome.

CONTENTS

I. The problem

II. Simple abundance modeling

III. The challenge of quantitation

References

I. THE PROBLEM

Nucleation theory is predicated on evolution of the "precritical cluster distribution", something that in gas and liquid phase nucleation and growth studies is difficult to approach experimentally except perhaps statistically e.g. via a scattering technique. In solid-state nucleation and growth settings, however, the "quench" often allows one to freeze the distributions in place for a cluster-bycluster look.

Czochralski semiconductor-silicon is an interesting case in point¹. Oxygen from the growth crucible, initially uninvited, has proven to be an ally to the device manufacturing process by strengthening the wafer and by precipitating to create defects capable of trapping electrically active impurities thus improving device yields. There is therefore practical interest, by the integrated-circuit and solar-cell industries, in control of oxygen-cluster behavior. Moreover, unclustered oxygen (in the 10-20 ppm range) may be mapped across a wafer via infrared absorption, while the very earliest stages of oxygen clustering (in the 450-550C range) are connected to thermal donors which, albeit avoided by the industry, may be used to characterize clusters via their effects on the bandgap with exquisite sensitivity.

In this note we use oxygen in semiconductor-silicon to discuss: (i) Boltzmann-factor visualizations of subcritical cluster distributions in the solid-state, and (ii) strategies for exploring them in the TEM.



FIG. 1. Boltzmann-factor cluster-distributions discussed in the text.

II. SIMPLE ABUNDANCE MODELING

Figure 1 is a schematic of the Boltzmann probabilityfactors as a relative measure of the steady-state cluster number/unit-volume, versus cluster size, for (a) the hot silicon after solidification in blue, (b) the "as-grown" distribution in a given part of the ingot after gradual cooldown in the Czochralski puller. This is stepped simply because we lowered the temperature in 50C increments in the simulation, and (c) after one (left) or two (right) "growth steps", the last of these steps at 1000C to facilitate the diffusion needed to precipitate most of the wafer oxygen if post-critical clusters are available.

These schematic distributions evolve simply: Below critical radius tiny clusters grow or evaporate quickly to the Boltzmann steady-state, while above critical radius at the current temperature the distribution simply translates rightward as more oxygen is added. As you can see in Fig. 1, for instance, the 1000C treatment in the absence of an 800C growth step has found too few clusters above critical size at 1000C (the appropriate vertical line) to result in a detectable number of growing precipitates.

Fig. 1 also suggests that as-grown silicon is sure to contain a respectable number of clusters in the very-small size regime. Heat treatments like that at right (followed by significantly more growth time) is the standard way in



FIG. 2. Stacking fault associated with late stage oxygen precipitation, whose known habit plane and intersection with the top and bottom surfaces of the thinned silicon specimen allows for rather precise local thickness determination. The field-width of this 300[keV] electron image is about 3.98 [m], making the projected breadth of the stacking-fault truncations about 656 [nm]. Multiplying by Tan[54.7°] for the angle between {111} and the {100} beam direction gives us a (quite large) local specimen thickness of about 0.92 [μ m].

which that subcritical distribution is characterized (followed by either TEM or etching), as well as how precipitates are created for use in the device manufacturing process itself.

III. THE CHALLENGE OF QUANTITATION

To be quantitative in finding the number of grown precipitates (or "developed clusters") per unit volume, quantitative ways to measure specimen thickness are needed. In silicon ion-milled specimens, for instance, interstitial {111} stacking-faults (created by Si interstitial displacement during precipitation) which intersect specimen top and bottom provide a direct geometric measure (cf. Fig. 2). Other methods under development and use for silicon include single-crystal thickness-fringes, energyfiltered TEM, and (at lower spatial-resolution laterally) color-changes of transmitted light².

You can see from Fig. 1, we should be able to examine the pre-critical nuclei (or "latent clusters") as their abundance is at least as great. The problem is that these clusters may be un-strained. With neither strain-fields nor a Z-contrast advantage, this means that searches of only very thin regions with minimal surface "noise"³ will show promise. Hence the quest for specimen-preparation strategies, and instruments able to locate (and characterize) such tiny cluster-distributions in important materials, continues.

- * pfraundorf@umsl.edu; also Physics, Washington U. (63110), St. Louis, MO, USA
- ¹ Fumio Shimura, *Semiconductor Silicon Crystal Technology* (Academic Press, 1989).
- ² J. P. McCaffrey and J. Hulse, "Transmitted color and interference fringes for TEM sample preparation of silicon,"

Micron 29, 139–144 (1998).

³ Shuhan Lin, Iris Mack, Noom Pongkrapan, and P. Fraundorf, "Ten nanometer surface intrusions in roomtemperature silicon," Electrochemical and Solid-State Letters 5, G83–G85 (2002).