

Frequency Combs: The purest microwave oscillations Enrico Rubiola, Giorgio Santarelli

► To cite this version:

Enrico Rubiola, Giorgio Santarelli. Frequency Combs: The purest microwave oscillations. Nature Photonics, 2013, 7, pp.269-271. 10.1038/nphoton.2013.79 . hal-00931767

HAL Id: hal-00931767 https://hal.science/hal-00931767v1

Submitted on 28 Sep 2024

HAL is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers. L'archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d'enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.



Distributed under a Creative Commons Attribution - NonCommercial 4.0 International License

FREQUENCY COMBS

The purest microwave oscillations

A new femtosecond frequency comb scheme is capable of generating microwave signals at a noise level below the shot noise of light.

Enrico Rubiola and Giorgio Santarelli

espite the fact that time (and equivalently frequency) is the physical quantity that we can measure most accurately, the demand for more precise and spectrally purer electrical oscillators is continually growing. Although optical techniques have a significant part to play in the race towards the ideal oscillator, they have some particularly challenging problems. The oscillator we consider here is a mode-locked femtosecond laser whose optical signal is converted to a microwave signal by photodiode detection. The spectral purity of a photonic oscillator is determined by its signal-to-noise ratio, which is the ratio of the thermal and shot noise to the microwave power. This measure is proportional to the optical power *P* in the thermal region, and to \sqrt{P}

at high optical power for which the shot noise exceeds the thermal noise of the photodiode output load. An important question is whether it is possible to overcome these noise limits.

Reporting in *Nature Photonics*, Franklyn Quinlan and colleagues have now demonstrated that Poisson statistics does not apply to the sharp light pulses generated by a femtosecond frequency comb¹. Consequently, at high optical power, the jitter of the photodetected microwave oscillation can be lower than a generally agreed limit due to shot noise. Circumventing the classical shot noise therefore results in a net improvement in the microwave spectral purity. Using this principle, Quinlan *et al.* have realized a noise floor for photodetected pulse train timing of 25 zs Hz^{-1/2}, which corresponds to a phase noise of -179 dBc Hz⁻¹ for a 10-GHz carrier¹; this is ~5 dB below that predicted by the accepted stationary (timeinvariant) shot-noise behaviour.

It is insightful to consider the origin of the terms 'jitter' and 'spectral purity'. For historical reasons, the oscillator spectral purity is described by $L(f) = S_{\varphi}(f)/2$ and is expressed in decibels relative to the carrier (dBc). The quantity $S_{\varphi}(f)$ is the power spectral density of the random phase φ as a function of the Fourier (offset) frequency *f*. Alternatively, we can use the phase-time fluctuation $x = \varphi/2\pi v$, where v is the carrier frequency. The associated power spectral density is given by $S_x(f) = (1/2\pi v)^2 S_{\varphi}(f)$. For example, -180 dBc at 10 GHz carrier gives $\sqrt{S_x} = 2.25 \times 10^{-20}$ s Hz^{-1/2} (Fig. 1).

High-spectral-purity oscillators have a wealth of potential applications. Among them, modern radar is one of the most demanding. The typical carrier frequency for radar is in the 10-GHz band, and the measurement time is determined by the target range and speed. The ability to detect small targets in cluttered and hostile environments depends on the oscillator phase noise. Some particle accelerators require a very low jitter of a few femtoseconds. High spectral purity increases with increasing carrier frequency because the phase-time fluctuation x is proportional to $1/\nu$.

A classical rule states that the additive phase noise is given by $S_{\varphi}(f) = N/P_{\mu}$, where P_{μ} is the microwave carrier power and N is the noise power spectral density, which accounts for shot effect and thermal energy, and includes the noise figure when appropriate. By using highpower photodiodes, Quinlan *et al.* have overcome this limitation by operating their photodiodes in the pulsed shot-noise regime. The underlying principle of their approach is both conceptually simple and technically difficult.

The shot noise is generally treated as a Poisson process; that is, a stream of memory-free statistically independent events. The associated power spectral density is $N_{\rm sh} = 2qIR$, where q is the electron charge, I is the average photocurrent and R is the load resistance (usually 50 Ω). The implicit assumption



Figure 1 | Power spectral density of random phase for a 10-GHz femtosecond frequency comb detected with a high-power photodiode and expressed in terms of different units. The brown and light-blue lines are the shot noise given by Quinlan *et al.*¹ in the stationary and pulsed shot-noise regimes, respectively. By further reducing the shot noise, the pulsed shot-noise floor could reach the thermal noise (dashed line), unless the microwave power increases proportionally. Flicker (1/f) noise is inherent in the detectors; the lowest flicker noise is observed at –133 dBc at 1 Hz (solid purple line). Owing to the photodiode flicker, the full advantages of the pulsed-shot regime are attained only at 100 kHz and beyond. At the lowest frequencies, the flicker-of-frequency noise of the Fabry-Pérot cavity (grey line with slope 1/f³) may limit the spectral purity.

that the noise is stationary is not valid in this case; rather, the femtosecond comb is a relatively extreme cyclostationary process. The statistics depends strongly on the origin of time, but repeats with the repetition rate v_{R} . Instead of having a uniform distribution, the shot noise is clustered around the light peaks. There is no noise during the dead time, when the light is off. The sharp periodic pulses introduce a periodic structure in the noise spectrum, which Quinlan *et al.* have exploited to reduce the phase noise¹.

The pulsed shot-noise regime is based on the wavefunction $|\Psi|^2$ and on its semiclassical interpretation as the detection probability in either space or time. If a photon's time of arrival is affected by an uncertainty σ , which is equal to the pulse half-width (standard deviation), the timing of an *m*-photon pulse will be a factor of \sqrt{m} more precise. Consider, for example, a stream of 4×10^{17} photons s⁻¹ (~8 mW, depending on the wavelength) in 1-ps pulses with a repetition rate of 2 GHz. Because each pulse contains 2×10^8 photons, the total jitter will be 7×10^{-16} s, uniformly distributed from zero to the Nyquist frequency (1 GHz). However, this trivial reasoning hides the need to master a series of cutting-edge technologies (such as an ultrapure Ti:sapphire laser,

pulse interleaving and high-power photodiodes), not to mention numerous experimental subtleties.

The generation of very pure microwave signals from optics has been explored by several groups²⁻⁵ using Ti:sapphire femtosecond lasers and erbium-doped fibre femtosecond lasers. Hopefully, in the near future, micrometre-scale resonators will be used to implement a miniature frequency comb⁶. The optoelectronic oscillator⁷ is an alternative path for which the classical shot noise applies; this scheme has never achieved a floor lower than approximately –160 dBc.

The femtosecond laser is very stable at f > 100 kHz (ref. 8), but its noise increases rapidly with decreasing *f*. High frequency stabilization in a high-finesse Fabry–Pérot cavity overcomes this limitation⁹, and is needed in most practical cases. A state-of-the-art Fabry–Pérot cavity shows a fractional frequency stability approaching 10^{-16} for measurement times in the range 0.1–1 s (refs 10,11). The reported data indicate that the cavity stability is certainly better than –170 dBc at an offset of 1 kHz (10 GHz carrier).

Among microwave oscillators, the sapphire whispering-gallery oscillator offers the highest spectral purity and it is based on reliable technology. At room temperature, a 10-GHz oscillator has a phase noise of $-160 \text{ dBc} (2.2 \times 10^{-19} \text{ s Hz}^{-1/2})$ at 1 kHz offset (ref. 12). The liquid-helium version¹³ is of great interest because it has a narrower resonator linewidth (<100 kHz at 300 K to a few hertz at 5 K). Both the room-temperature and cryogenic devices are mature, fully engineered and reliable oscillators¹⁴. The pulsed shot-noise regime realized by Quinlan *et al.* challenges sapphire-based technology.

In principle, the narrow optical pulses and wide optical bandwidth required by the femtosecond mechanism will give an extremely low phase noise that is much lower than any practical measurement capability. On the other hand, the duration of the microwave pulses is determined by the photodiode and the microwave bandwidth. Such electrical pulses are several orders of magnitude longer than the optical pulses and are subject to phase fluctuations. Moreover, experience indicates that the amplitude noise is difficult to control and affects the phase noise.

The optical comb enables a phase noise that is significantly lower than the

experimental spectra. The floor given by the ratio of the thermal noise to the microwave power gives a lowest bound for the phase noise. At sufficiently high optical powers, the shot noise in the detector will exceed the thermal noise. The experimental discovery of the pulsed shot-noise regime by Quinlan et al.¹ provides insights into the detection mechanism and opens the way to improve the spectral purity of oscillators. On the other hand, this regime is difficult to manage and requires photodiodes capable of operating in the linear regime at high peak powers of over 100 mW. Further progress depends on advances in semiconductor technology. Finally, the best available photodiodes are affected by 1/f phase noise, which is about -133 dBc at an offset of 1 Hz. This is quite a difficult technical problem. Microwave amplifiers and other active devices that can be used at the photodiode output are affected by an even higher 1/f phase noise. Thus, the 1/f noise represents a technical problem that can be overcome only by efforts in the fields of optics, semiconductor technology and microwave engineering.

Enrico Rubiola is at the Time and Frequency Department, CNRS FEMTO-ST Institute, ENSMM, 26 Chemin de l'Epitaphe, 25030 Besancon, France. Giorgio Santarelli is at the Laboratoire de Photonique, Numérique et Nanosciences (LP2N), CNRS, Université de Bordeaux 1, Institut d'Optique, 351 Cours de la Libération, 33405 Talence, France.

e-mail: *rubiola@femto-st.fr*

References

- 1. Quinlan, F. et al. Nature Photon. 7, 290-293 (2013).
- 2. Kim, J. & Kärtner, F. X. Opt. Lett. 35, 2022-2024 (2010).
- 3. Fortier, T. M. et al. Nature Photon. 5, 425-429 (2011).
- 4. Haboucha, A. et al. Opt. Lett. 36, 3654–3656 (2011).
- 5. Jung, K. & Kim, J. Opt. Lett. 37, 2958–2960 (2012).
- Kippenberg, T. J., Holzwarth, R. & Diddams, S. A. Science 332, 555–559 (2011).
- Eliyahu, D., Seidel, D. & Maleki, L. *IEEE Trans. Microw. Theory* 56, 449–456 (2008).
- Benedick, A. J., Fujimoto, J. G. & Kärtner, F. X. Nature Photon. 6, 97–100 (2012).
- 9. Fortier, T. M. et al. Nature Photon. 5, 425-429 (2011).
- 10. Jiang, Y. Y. et al. Nature Photon. 5, 158-161 (2011).
- Kessler, T. et al. Nature Photon. 6, 687–692 (2012).
 Ivanov, E. N. & Tobar, M. E. IEEE Trans. Ultrason. Ferroelectr. Freq. Control 56, 263–269 (2009).
- Hartnett, J. G., Nand, N. R. & Lu, C. Appl. Phys. Lett. 100, 183501 (2012).
- 14. Giordano, V. et al. Rev. Sci. Instr. 83, 085113 (2012).