Radioisotopes Médicaux Innovants, RaMI



Physics of Radiation InteractionS with Matter and Applications







Expertises scientifiques et responsables

Physique nucléaire, interaction rayonnement matière, données nucléaires, détecteurs, mesures, simulations

ES1 : Radionucléides Médicaux Innovants – RaMI

Santé, médecine nucléaire, radionucléides

ES2 : Interaction Rayonnement Matière – IRMa

Ion Beam Analysis IBA, matériaux,

Contrôle non destructif CND, PIXE/PIGE, RX

ES3 : Hadronbiologie – HB

Santé, radiobiologie, hadronthérapie flash













Conventional imaging in oncology

Visualize and localize tumors, measure them and evaluate the response to treatments



Centre François Baclesse Radiography



Centre René Gauducheau

Computerized Tomography Scanner



Institut Roi Albert II Magnetic Resonance Imaging

A gain can be obtain by coupling them with nuclear medicine technique (SPECT or PET) which gives these information



but give limited information on the metabolism



These techniques allow to get accurate information on the morphology

12 juin 2019







Conventional radiotherapy

External beam radiotherapy:

- X rays, gamma, electrons
- Hadrontherapy



Brachytherapy



Institut de cancérologie de l'Ouest



ProteusOne, IBA



Institut de cancérologie de l'Ouest

These techniques are very efficient to treat a localized disease

Limit: does not target disseminated disease or residual disease

This can be address by nuclear medicine techniques





12 juin 2019





Great progress in the last ten years

Multimodality: SPECT/CT, PET/CT then PET/MR







5

12 juin 2019





Motivations

Nuclear medicine

Many useful / potentially useful isotopes identified for applications in nuclear medicine

Cyclotrons and accelerators being used in an increasing number of countries along with reactors

- Diagnosis (γ , β^+)
- Therapy (β -, α , e_{Auger})

Nuclear data

- Accurate and reliable sets of data
- Well defined production routes and decay properties
- Optimum production of specific radionuclides, minimization / elimination of impurities, realistic dose calculations

Nuclear data needs addressed by successive:

- Experimental physicist generations
- IAEA Coordinated Research Projects initiated in the 90's, European FPs, national programs

Nuclear codes

Provide a large set of nuclear data in terms of targets, projectiles and energy range to constrain and develop predictive simulation tools of nuclear reactions



Séminaire Recherche IMT Atlantique





Motivations

A large set of radioisotopes with very different characteristics is suitable:

- Radiation type for the different applications Half-life to match the bio-distribution time
 Chemical properties to attach to the vector molecule
- Production yields to get the **purest product** Prod. capacities to envisaged **large scale use**

The nuclear physicist could have crucial contribution:

- Identify production route and define production process (spallation, fission or activation)
- Identify and quantify contaminants Discuss with physicians to promote its use

Over the last years, several radionuclides have emerged:

- β^+ : Cu-64, Ga-68, Zr-89 ... γ : Sn-117m ...
- β⁻: Ho-166, Lu-177 ... α: At-211, Bi-212, Bi-213, Ra-223, Ac-225 ...
- Theranostic: Sc-44/Sc-47, Cu-64/Cu-67, Ga-68/Lu-177 ...
- Auger: Sn-117m, Tb-155 (at the research level for the moment) Terbium quadruplet: Tb-149, 152, 155, 161

To do so, we possess facility (will possess) available for irradiations equipped with experimental techniques







Stacked-foil technique

Stacked-foil technique:

- Target/monitor/degrader **pattern**
- Thin foils:
 - E loss small and constant
- One cross section value per foil

Activity and cross section:

$$\sigma = \frac{\operatorname{Act.A}}{\chi.\Phi.\mathcal{N}_{A}.\rho.e.(1 - e^{-\lambda.t})}$$



Irradiation station and beam line

Use of a Faraday cup:

- Beam dump placed at the end of the stack to control the intensity during the irradiation

Use of a monitor foil:

$$\sigma = \sigma' \cdot \frac{\chi' \cdot \operatorname{Act} \cdot A \cdot \rho' \cdot e' \cdot (1 - e^{-\lambda' \cdot t})}{\chi \cdot \operatorname{Act}' \cdot A' \cdot \rho \cdot e \cdot (1 - e^{-\lambda \cdot t})}$$

• error on e, e':
$$\leq 1\%$$

• error on t: negligible

IAEA recommended cross sections:

- 11 reactions available for protons
- ²⁷Al (2), ^{nat}Ni, ^{nat}Ti (2), ^{nat}Cu (5), ^{nat}Mo
- 11 reactions available for deuterons
- ²⁷Al (2), ^{nat}Fe, ^{nat}Ni(3), ^{nat}Cu (5), ^{nat}Ti(2)
 6 reactions available for alpha-particles
 ²⁷Al (2), ^{nat}Ti and ^{nat}Cu (3)







12 juin 2019

Collected data sets

Proton induced reactions:

Ac-225 from Th-232(p,x) Ra-223 from Th-232(p,x) Fission fragment distribution from Th-232(p,x) Monitor reactions on Ti, Ni and Cu

Deuteron induced reactions:

Sc-44 New data set for Ca-44(d,x) Tb-155 New data set for Gd-nat(d,x) Re-186g New data set for W-186(d,x) Th-226 New data set for Th-232(d,x) Fission fragment distribution from Th-232(d,x) Hg-197m from Au-197(d,2n) Monitor reactions on Ti

Alpha induced reactions:

Sn-117m from Cd-116(α ,x) Ru-97 from Mo-nat(α ,x) Monitor reactions on Cu, Ti, Ni C. Duchemin et al, Phys Med Biol 60 (2015) 931-946
C. Duchemin et al, Phys Med Biol 60 (2015) 931-946
V. Métivier et al, EPJ Web of Conf. 146 (2017) 08008
E. Garrido et al., Nucl Instr Meth Phys Res B 383 (2016) 191-212

C. Duchemin et al, Phys Med Biol 60 (2015) 6847-6864
C. Duchemin et al, Appl Radiat Isot 118 (2016) 281-289
C. Duchemin et al, Appl Radiat Isot 97 (2015) 52-58

- V. Métivier et al, EPJ Web of Conf. 146 (2017) 08008
- E. Nigron et al, Varenna (2018)
- C. Duchemin et al, Appl Radiat Isot 103 (2015)160-165

C. Duchemin et al, Appl Radiat Isot 115 (2016) 113-124M. Sitarz et al, Instruments (2019), 3, 7







9

Pa-230 as a precursor of an α generator



TALYS

TALYS

- Code for the simulation of nuclear reactions
- Many state-of-the-art nuclear models
- Provide a complete description of all reactions channels and observables Targets : Z = 3 to 110

Nuclear reactions

batech



 \Rightarrow Influence on the calculated production cross section values

Koning A.J. and Rochman D., Nucl. Data Sheets, 113, 2012

Projectiles : n, p, d, t, He-3, α particles

Energy : 1 keV to 1 GeV





11

Adapted from S. Benck, PhD thesis, 1999

Pa-230 as a precursor of an α generator



Pa-230 as a precursor of an α generator



TALYS

TALYS default and adjusted calculations

TALYS code version 1.9

the combination of models that best describes the whole set of available data for all projectiles, targets and incident energies defined by the TALYS authors ⇒TALYS 1.9 Default

One combination of models that best describes our whole set of data for proton, deuteron, alpha particles as projectile (and also some literature data) has been defined by A. Guertin et al. ⇒TALYS 1.9 Adj.

Models	Projectile	Default	Adj.
Optical	p (1)	A.J. Koning and J.P. Delaroche (2003)	A.J. Koning and J.P. Delaroche (2003)
	d (5)	S. Watanabe (1958)	Y. Han et al. (2006)
	α (8)	V. Avrigeanu et al. (2014)	Demetriou et al. (2002)
Pre-equilibrium	All (4)	Two-component exciton model Numerical transition rates with E- dependent matrix element A.J. Koning and M.C. Duijvestijn (2004)	Two –component exciton model Numerical transition rates with optical model for collision probabilities A.J. Koning and M.C. Duijvestijn (2004)
Level density	All (6)	Constant temperature and Fermi gas model A.J. Koning et al. (2008)	Microscopic level density (Skyrme force) from Hilaire's combinatorial tables Goriely et al. (2008)





Pa-230 as a precursor of an α generator



Re-186g: proton/deuteron production route

Re-186g ($T_{1/2} = 3.7$ d), β - emitter used in clinical trials for the palliation of painful bone metastases resulting from prostate and breast cancer



Re-186g: proton/deuteron production route

Deuteron induced reaction has clearly a highest Re-186g production cross section



Re-186g: deuteron production route



Re-186g: deuteron production route



Novel therapeutic and imaging nuclide

Sn-117m ($T_{1/2} = 13.6$ d), conversion e- emitter used for the palliation of painful bone metastases 158 keV gamma ray suitable for SPECT imaging



Novel therapeutic and imaging nuclide



Terbium 155: theranostic isotope

Tb-155 ($T_{1/2} = 5.3$ d), theranostic isotope for SPECT imaging and Auger therapy



Terbium 155



Conclusions

Nuclear medicine

Many useful / potentially useful isotopes identified for applications in nuclear medicine

- Personalized medicine

The Right Drug To The Right Patient For The Right Disease At The Right Time With The Right Dosage

Nuclear data

A large set of data have been collected using the stacked-foil technique at ARRONAX

- with different type of projectiles (proton, deuteron and alpha particles)
- for materials all over the mass range
- for diagnosis and therapy purposes in nuclear medicine

To achieve:

- optimum production of specific radionuclides
- minimization or elimination of impurities
- realistic dose calculations

Comparisons have been performed systematically with the TALYS 1.9 code

- state of the art models included
- possibility to combine models to better describe data
- a set of models have been found to allow a good description of all our collected data







Séminaire Recherche IMT Atlantique

Merci de votre attention

"Radioisotopes Médicaux Innovants, RaMI"

A. Guertin¹

1 SUBATECH, IMT Atlantique, Université de Nantes, CNRS/IN2P3, Nantes, France



Physics of Radiation InteractionS with Matter and Applications





25

12 juin 2019

