

Chromosome-level hybrid de novo genome assemblies as an attainable option for non-model insects

Coline C Jaworski, Carson W. Allan, Luciano M Matzkin

▶ To cite this version:

Coline C Jaworski, Carson W. Allan, Luciano M Matzkin. Chromosome-level hybrid de novo genome assemblies as an attainable option for non-model insects. Molecular ecology resources, 2020, 20 (5), pp.1277-1293. 10.1111/1755-0998.13176. hal-02559227

HAL Id: hal-02559227 https://hal.science/hal-02559227

Submitted on 30 Apr 2020 $\,$

HAL is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers. L'archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d'enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.





25 Abstract

26 The emergence of third generation sequencing (3GS; long-reads) is making closer the goal of 27 chromosome-size fragments in *de novo* genome assemblies. This allows the exploration of new 28 and broader questions on genome evolution for a number of non-model organisms. However, 29 long-read technologies result in higher sequencing error rates and therefore impose an elevated 30 cost of sufficient coverage to achieve high enough quality. In this context, hybrid assemblies, 31 combining short-reads and long-reads provide an alternative efficient and cost-effective approach 32 to generate *de novo*, chromosome-level genome assemblies. The array of available software 33 programs for hybrid genome assembly, sequence correction and manipulation are constantly being expanded and improved. This makes it difficult for non-experts to find efficient, fast and 34 35 tractable computational solutions for genome assembly, especially in the case of non-model 36 organisms lacking a reference genome or one from a closely related species. In this study, we review and test the most recent pipelines for hybrid assemblies, comparing the model organism 37 Drosophila melanogaster to a non-model cactophilic Drosophila, D. mojavensis. We show that 38 39 it is possible to achieve excellent contiguity on this non-model organism using the DBG2OLC 40 pipeline.

41

42

43

Keywords: de novo assembly; non-model species, long-read, short-read, genomics, merged assembly.

53

60

1 INTRODUCTION

45 Whole genome sequencing is a major target in evolutionary biology, because it provides the 46 material to study how a species' genome evolves. Notably, whole genome data provides the 47 opportunity to study recombination and large rearrangement events, differential molecular 48 evolution across the genome, and imprints of selection throughout the genome, ultimately 49 improving our knowledge of how species evolve and diverge (Ellegren 2014; Rudman et al., 50 2018). To increase our understanding of such evolutionary processes, we need to expand the 51 range of studied organisms to non-model organisms, for which the access to well resolved 52 genome assemblies is often lacking.

Thanks to third generation sequencing (3GS) from platforms such as PacBio (Rhoads & Au 2015) and Nanopore (Urban, Bliss, Lawrence & Gerbi 2015), *de novo* genome assemblies of nonmodel organisms can be obtained, but one drawback from such technologies is the high error rate. *De novo* hybrid assemblies combine long-reads and short-reads (Illumina technology; Bentley et al., 2008) to achieve high contiguity and accuracy while reducing sequencing costs through lower coverage of long-reads data (Ye, Hill, Wu, Ruan & Ma, 2016).

There is a constantly increasing panel of tools to assemble reads and polish genome assemblies. 61 62 Identifying the pipeline most optimized to one's needs is one obstacle, and applying it to the 63 actual data is another one, especially in the absence of bioinformatic expertise, since guidelines 64 and practical implementations remain limited. In addition, many of those pipelines are not tested on non-model organisms and assume that the samples are from model organisms where extreme 65 66 inbreeding and high homozygosity is commonly feasible. In the present study, we reviewed the most recent whole genome assembly pipelines, and selected a promising pipeline relying on 67 68 hybrid technology (Chakraborty, Baldwin-Brown, Long & Emerson, 2016). We tested it 69 thoroughly with the aim of an optimized assembly, using DNA data from both Drosophila 70 melanogaster as a model species, and D. mojavensis from the Sonora, Mexico population as a 71 non-model species. Drosophila mojavensis is a cactophilic North American desert endemic 72 species, ovipositing, developing and feeding as adults on necrotic cactus tissues (Heed 1978). 73 The species is composed of four distinct host populations (Sonoran Desert, Baja California,

74 Mojave Desert and Santa Catalina Island) each utilizing a different cactus species (population 75 from Sonora utilizes the organpipe cactus, *Stenocereus thurberi*). Given its known ecology and 76 ever-growing genomic tools, this species has become a model for the study of the genomics of 77 local ecological adaptation and speciation (Matzkin et al., 2006; Bono, Matzkin, Kelleher & 78 Markow, 2011; Matzkin 2014; Benowitz, Coleman & Matzkin, 2019). Distantly related to D. 79 melanogaster, D. mojavensis has a similar genome size (see Table 1) and six Muller elements, 80 although all its chromosome are acrocentric (Drosophila 12 Genomes Consortium 2007; 81 Schaeffer et al., 2008). Ultimately, this new D. mojavensis assembly from Sonora will be used in 82 a much larger upcoming genomic study using *de novo* assemblies of multiple cactophilic species and populations (Matzkin, unpublished data). We provide here an analysis of the effects of 83 84 different parameters on the quality of the final assembly, assessed by a combination of universal 85 tools (contigs length and N50 as a measure of contiguity; BUSCO score as a measure of quality 86 and completeness (Waterhouse et al., 2017) and a reference-based tool, Quast (Gurevich, Saveliev, Vyahhi & Tesler, 2013) which compares the assembly to a reference genome. We 87 show a significant improvement of assembly quality of *D. melanogaster* compared with results 88 89 from Chakraborty et al. (2016) simply by tuning parameters and we provide guide parameters for 90 assemblies with similar coverage of non-model organism DNA. Finally, we tested the pipeline 91 on D. mojavensis from the Santa Catalina Island, California population using Nanopore long-read 92 data instead of PacBio data.

93 94

95 2 MATERIALS AND METHODS

96 2.1. Drosophila mojavensis sequencing

97 We used flies from a *D. mojavensis* isofemale line (MJ 122) originally collected in Guaymas, 98 Sonora Mexico in 1998, thereafter SON. This isofemale line has been maintained since its 99 collection under laboratory conditions (25° C and 14/10 day/night cycle), transferred every 100 generation (four weeks) into fresh 8-dram vials containing banana-molasses medium (Coleman, 101 Benowitz, Jost & Matzkin, 2018). Prior to DNA extraction the flies were raised on banana-102 molasses medium with 125 µg/ml ampicillin and 12.5 µg/ml tetracycline to reduce bacteria 103 contamination of the sequencing data. The sequencing methods for short-read data (paired ends

and mate pairs) have been described in Allan & Matzkin (2019). Sequencing technologies andcoverage for the different data sets are summarized in Table 1.

106

107 2.1.2. DNA extraction for PacBio Sequencing – Protocol optimization

108 Due to the long-read potential of PacBio Sequencing Systems, extra care must be taken during 109 extraction to produce high molecule weight DNA. Attempts at using both QIAGEN DNeasy 110 Blood & Tissue Kit and QIAGEN MagAttract HMW DNA Kit failed to produce sufficiently long 111 strands of DNA. As such, a chloroform-based extraction method was used. This relatively 112 simple method is low cost and the only specialized equipment needed is a refrigerated centrifuge. To consistently recover enough DNA for two PacBio libraries, 150 flies of each sex were used 113 114 for extraction. Flies were starved for two hours in groups of 50 per vial and then frozen at -80° C in 1.5 mL tubes. A lysis solution containing Tris HCI buffer 0.1M pH 8.0, EDTA 0.1 M pH 8.0, 115 116 and 1% SDS was prepared and stored at room temperature to prevent the SDS from precipitating. While on ice, 500 μ L of lysis solution was added to each tube of flies, followed by 2.5 μ L of 117 QIAGEN Proteinase K to reduce DNA degradation. Using a plastic pestle, flies in each tube 118 119 were hand-homogenized by gently grinding them. Hand homogenization resulted in slightly 120 lower amounts of DNA recovered, however the size of DNA fragments were longer compared to 121 when using a battery-operated pestle motor to homogenize. The mixture was incubated at 65 °C 122 for 30 min with gentle mixing halfway through. To further reduce DNA fragmentation, tubes 123 were cooled to 37 °C for three minutes and another 2.5 µL of QIAGEN Proteinase K was added. 124 Tubes were incubated for an additional 30 min at 37 °C. After incubation, 70 µL of 4 M 125 potassium acetate was added, mixed by inversion, and then placed on ice to incubate for 30 126 minutes. In a 4 °C Eppendorf 5920R centrifuge, the tubes were spun for 30 min at 18,000 rcf to 127 pull debris to the bottom of the tubes. For each tube, the supernatant was transferred to new 128 tubes avoiding as much debris as possible. One volume of chloroform: isoamyl alcohol 24:1 was added to each tube and gently inverted 40 times, and then centrifuged at 4 °C for 5 min at 129 130 10,500 rcf. The upper phase was transferred to a new tube while being careful to not disturb the interface. The DNA was precipitated by adding 350 µL of 2-propanol and gently inverting the 131 132 tube. At this point visible threads of DNA were apparent. To pellet the precipitate, the tubes 133 were centrifuged at 4 °C for 5 min at 10,500 rcf. The supernatant was discarded and the pellet

134 was washed with 1 mL of room-temperature 70% ethanol. The tube was inverted to insure 135 washing of the pellet and tube. A final 4 °C centrifugation for 2 min at 10,500 rcf was 136 performed. The ethanol was removed with a pipettor as completely as possible and the pellet 137 dried for 10-15 min in a fume hood. 30 µL of Tris-EDTA pH 8.0 was added to each tube to 138 resuspend the DNA. While the pellet normally goes into solution relatively easily, it can be 139 placed at 4 °C overnight to insure resuspension. The six tubes were then combined to a single 140 tube and 3 µL of QIAGEN RNaseA was added and incubated for 30 min at 37 °C. The DNA was 141 delivered as this resuspended solution for PacBio sequencing.

142

143 2.1.3. PacBio Sequencing

144 PacBio sequencing was performed at the Arizona Genomics Institute (Tucson, AZ, U.S.A.). 145 DNA was sized in a 1% agarose pulsed field gel electrophoresed at 1-50 sec linear ramp, 146 6 volts/cm, 14 °C in 0.5X TBE buffer for 20 hours (BioRad). The marker used was a lambda ladder Midrange PFG I (New England Biolabs). The resultant DNA smear had a large mass in 147 the 35-65 kb range (Fig. 1). DNA purity was verified using a NanoDrop One Microvolume UV 148 149 Spectrophotometer with ratios 260/280 and 260/230 over 1.8. Quantity (150 ng/ μ L in 180 μ L = 150 27 µg) was determined by a Qubit Fluorometer (Life Technologies), and was consistently lower than that measured with the Nanodrop. PacBio sequencing libraries were prepared from 6 µg 151 152 starting material each, following manufacturers protocol for a 20 Kb Template Preparation Using BluePippinTM Size-Selection System (www.pacb.com). The library was size-selected, on a 153 154 BluePippin, at 20 kb using high pass with S1 Marker (Sage Sciences). The final library was 155 damage-repaired, bead-purified and quantified. Sequencing was performed on a PacBio Sequel 156 instrument following manufacturer's instructions. The sequencing primer annealed was v3, the 157 sequencing kit was v2.1. Two libraries were loaded on two separate SMRT cells with magbeads 158 at concentrations of 25 pmol and 35 pmol, respectively. Sequencing was carried out for 159 collection of 10 hr movies on 1 M SMRT cells.

160

161 2.2. Drosophila melanogaster and D. mojavensis public sequencing data

162 To generate the *D. melanogaster* assembly (hereafter, Dmel), PacBio data was retrieved from the
163 NCBI Short-read Archive SRX499318 (Kim et al., 2014). This data set contained 42 PacBio RS

164 II SMRT cells from male D. melanogaster ISO1 flies. We used data from 20 randomly selected 165 cells only to obtain a coverage similar to our data sets (cell numbers SRR1204085, SRR1204088, 166 SRR1204451. SRR1204466, SRR1204467. SRR1204469. SRR1204471. SRR1204472. 167 SRR1204473, SRR1204481, SRR1204482, SRR1204485, SRR1204486, SRR1204615, 168 SRR1204617, SRR1204690, SRR1204691, SRR1204692, SRR1204693, and SRR1204696). We 169 used the SMRT Illumina HiSeq 2000 100 bp paired-end data from male D. melanogaster ISO1 170 flies, which was retrieved from the European Nucleotide Archive ERX645969 (Miller, Smith, 171 Hawley & Bergmann, 2013).

172

For the *D. mojavensis* assembly from the Santa Catalina Island, California population (hereafter,
CAT), Nanopore sequencing data was kindly provided by Miller, Staber, Zeitlinger & Hawley
(2018). Short-read Illumina data of *D. mojavensis* from Catalina was retrieved from the NCBI
Short-read Archive SRR6425997 (Miller et al., 2018) and of Sonora from NCBI BioProject
PRJNA530196 (Allan & Matzkin, 2019).

178

179 **2.3. Computing resources**

All the programs were run on the UA Research Computing High Performance Computing (HPC) at the University of Arizona. The cluster used is composed of 28 core processors with 168 gb RAM per node, and is run via a PBS-Pro grid system. All the programs used were installed under a user python virtual environment (pip). The majority of the programs used are available as Bioconda packages for easy installation in non-cluster environments (Grünings et al., 2018). They are also provided as Docker containers through Bioconda which can be run through *Singularity* (https://sylabs.io/) on cluster systems. All command lines are provided in Appendix.

- 187
- 188

189 2.4. Assembly pipelines

190 *2.4.1. DBG2OLC Pipeline*

191 The DBG2OLC Pipeline is composed of three main steps: (i) the hybrid assembly via the 192 DBG2OLC program, (ii) the long-read assembly only, and (iii) the merging of those two 193 assemblies (Fig. 2).

194

195 *(i) Hybrid assembly*

196 DBG2OLC uses contigs from a short-read assembly and maps them to the raw long-reads, which 197 are then compressed into the list of the short-read's contig identifiers (Ye et al., 2016). A best 198 overlap graph is constructed from those compressed long-reads before uncompressing them into a 199 consensus sequence. This method is both highly accurate and extremely fast (Ye et al., 2016). 200 Then, the consensus contigs, or backbones are corrected using Sparc (Ye & Ma, 2016). Sparc 201 builds a sparse k-mer graph (k-mers in different positions are treated independently) using the 202 contigs identifiers' list associated with each raw long-read. All short-read contigs are then aligned to their associated long-read using the Blasr aligner from the PacBio SMRT toolkit 203 204 (SMRT Link v4.0.0), previously *Pbdagcon*, which is the most time-consuming step. *Sparc* 205 finally uses these alignments to refine the graph and create a polished consensus sequence. In the 206 present study, we tested two competing short-read assemblers, SparseAssembler (provided with the DBG2OLC installation package) (Ye, Ma, Cannon, Pop & Yu, 2012), and Platanus version 207 1.2.4 (Kajitani et al., 2014). We used the March 2019 version of DBG2OLC (Ye et al., 2016), the 208 209 January 2015 version of Sparc (Ye & Ma, 2016), and Blasr 5.3.5 (b30da0) (SMRT Link v4.0.0). 210 Note that we began working with an older version of *Blasr* which was significantly slower and led to slightly different results. For this reason, and because programs often include third party 211 212 packages, it is important to keep track of each version used and physically separate the 213 repositories, so the SMRT toolkit was installed in an independent directory with no direct link to 214 the user bin, except for the Blasr program. We modified the split and run sparc.sh script 215 available from the Sparc Github repository so as to call the split reads by backbone.py script 216 externally (Appendix I), and to set the number of chores used by *Blasr* from the command line. 217 This way, it is easier to rerun the time-consuming Sparc step in case of crash from where it 218 stopped, and after moving the already corrected backbones into another directory.

219

The hybrid assembly was then polished using the PacBio tool in the SMRT toolkit (SMRT Link v4.0.0). The version of the PacBio correction tool is frequently updated along with chemistry technology of PacBio sequencing, therefore the version *Quiver* (v2.1.0) was used for *D. melanogaster* (sequenced in 2014 on a PacBio RS II system; Kim et al., 2014), and the version

224 Arrow (v2.1.0) was used for D. mojavensis (sequenced in 2017 on a PacBio Sequel system 225 installed with SMRT Link v4.0.0, see above). For simplicity, we will thereafter refer to that step 226 simply as 'Ouiver'. Ouiver aligns the raw PacBio reads to the assembled and corrected contigs 227 output by Sparc, and uses a consensus caller to polish them (Chin et al., 2013). Lastly, the hybrid 228 assembly was polished using Pilon v1.22 (Walker et al., 2014). Pilon uses raw short-reads 229 aligned to the assembly with the *Bowtie2* aligner version 2.2.9 (Langmead, Trapnell, Pop & 230Salzberg, 2009), to first find and correct SNPs and small indels (base error consensus), and 231 secondly local misassemblies (alignment discrepancies scan) that are reassembled using paired 232 ends and mate pairs (if provided). Parameters were optimized at each step: (a) choice of the short-read assembler (Platanus vs. SparseAssembler with kmer-size 39 or 53); (b) DBG2OLC 233 234 parameters, based on recommended optimization ranges (Ye et al., 2016): MinOverlap in [20; 150]; AdaptiveTh in [0.002; 0.02]; KmerCovTh in [2; 10] and MinLen in [200; 2,000]; default 235 values were otherwise used (k = 17; LD1 = 0); (c) ContigTh 0 (default) vs. 1 (recommended for 236 237 > 100x PacBio coverage only); and (d) Sparc one vs. two iterations. These parameters are 238 summarized in Table 2.

239

240 *(ii)* Long-read assembly only

241 The long-read assembly was created using *Canu* v1.5 (Koren et al., 2017), which significantly 242 outperforms its older version Celera Assembler (PbcR) used in Chakraborty et al. (2016) as well 243 as other assemblers, notably by using an adaptive kmer weighting which both improves the 244 efficiency and the quality of the assembly of highly repetitive genomic regions. We tested two 245 parameters for the correctedErrorRate: 0.039 vs. 0.055 (low end and middle value of 246recommended range, Table 3, Koren et al., 2017). Note that this adjustment is limited by coverage, and thus intrinsic to the analyzed data set. We ran the three Canu steps (correction, 247 248 trimming and assembly) separately using the options -correct, -trim and -assemble (see Appendix) to optimize the assembly step without running again the first two steps. Similarly to 249 250 the hybrid assembly, the long-read only assembly was polished using both *Ouiver* and *Pilon*.

251

252 (iii) Assembly merging

253 The hybrid assembly and long-read only assembly were merged after polishing using the 254 *Quickmerge* tool v0.2 (Chakraborty et al. 2016). *Quickmerge* uses *MUMmer* (v 3.0) (Kurtz et al. 255 2004) to align the two assemblies and find the unique best alignment (using the -delta-filter 256 option in MUMmer). Quickmerge then identifies high confidence overlaps between the two 257 assemblies to find seed contigs (i.e., contigs that can be extended at both ends). Finally, it 258 merges the overlapping contigs using sequences from the reference (donor assembly) into the 259 query (acceptor assembly). The optimization consisted of trying both the hybrid and long-read 260 assemblies as reference vs. query, and varying the I and Im cutoff parameters in *Quickmerge* 261 (Table 3). Lastly, the merged assembly was polished using *Quiver* and *Pilon*.

262

263 2.4.2. Test of the DBG2OLC pipeline with Nanopore long-reads

264 We ran the DBG2OLC pipeline on CAT sequencing data using Nanopore raw reads instead of 265 PacBio raw reads for the long-read only assembly, the hybrid assembly, and the polishing steps. 266 We used the optimal parameter set (2.4.1; P6), except for *Canu*, for which we had to increase the correctedErrorRate to 0.055 to recover 97% of the genome, while we could recover only 51% 267 268 using a correctedErrorRate of 0.039. Instead of *Quiver*, we used *Nanopolish* version 0.11.0 269 (Simpson et al., 2017). Similar to Quiver and Pilon, raw Nanopore reads were first aligned to the 270 target assembly using the Bwa aligner version 0.7.17 (Li & Durbin, 2010). Nanopolish then 271 generates an improved consensus sequence.

272

273 2.4.3. Alternative Pipelines

274 *DBG2OLC* was identified as the only pipeline, among the most recently published assemblers, 275 allowing the assembly of long-reads prior to correction. Alternatively, long-reads may be corrected prior to assembly, as is the case in the *Canu* pipeline. Other possible correction tools 276 277 include LSCplus (Hu, Sun & Sun, 2016), a modified version of the MHAP tool (indexing kmers used to build the assembly graph in Celera; (Carvalho, Dupim & Goldstein, 2016), HALC (Bao 278 279 & Lan, 2017), and FMLRC (Holt, Wang, Jones & McMillan, 2016), and most recently (not tested here) MECAT (Xiao et al., 2017) and Jabba (Miclotte et al., 2016). The LSCplus package was 280 not available at the time of our study, and we were therefore not able to assess its efficiency. The 281modified MHAP tool was implemented in Celera only (the older version of Canu), which thus 282

yielded poor results in term of assembly contiguity, and this solution was abandoned. Note
however that some aspects of kmers indexing as proposed in the modified *MHAP* tool have now
been implemented in *Canu* (Koren et al., 2017), and were therefore implicitly used in our *DBG2OLC* Pipeline. *FMLRC*, although it correctly performed the long-read correction, proved
to be non-compatible with *Canu* (Holt et al., 2016). Therefore, this alternative was abandoned as
well.

290 HALC corrects long-reads by (i) aligning them to the contigs from a short-read assembly, (ii) 291 constructing a graph from this alignment, and (iii) finding the best path in the graph to correct 292 each long-read. It relies on Blasr (SMRT Link v4.0.0) for the alignment and on LoRDEC (Salmela & Rivals 2014) for the correction. We used the one version of HALC available, Blasr 293 5.3.5 and LoRDEC 0.6 with the GATB library 1.0.6. After read correction with HALC, we ran 294 295 *Canu* (-assemble option) with a corrected ErrorRate = 0.039. The contiguity of the assembly was orders of magnitude worse than when using the *Canu* correction tool and the same assembly 296 parameters (HALC correction: N50 = 488,850; total length = 138,021,997; max length = 297 298 2874227; Canu pipeline: N50 = 10,9990,654; total length = 151,043,692; max length = 299 25,950,142). This might have been improved by parameter optimization of both the HALC 300 correction step and the assembly step with the *Canu* assembler, but due to the strong difference in 301 contiguity we chose to not utilize HALC. Therefore, we focused on optimizing the DBG2OLC 302 pipeline only.

303

289

304 2.5. Assembly quality check

305 Comparisons between assemblies and quality assessment were performed based on assembly 306 statistics from Quast version 4.6.2 (Gurevich et al., 2013) by comparing each assembly to a 307 reference genome to estimate the number of global and local misassemblies as well as the number of mismatches and indels. For both general statistics (number of fragments, N50) and error rates 308 309 (presented in Tables 4-6), we used contigs longer than 400 bp only, so as to run the program We also calculated BUSCO scores using the diptera (odb9) set of Benchmarking 310 faster. 311 Universal Single-Copy Orthologs (Waterhouse et al. 2017). We used the reference genomes FB2017 01and FB2015 02 (Consortium DG, 2007) released on FlyBase (Thurmond et al., 2019) 312

313 for Dmel and CAT, respectively. For SON, we used a template assembly constructed based on 314 the Catalina reference genome (Allan & Matzkin, 2019). For each data set, we extracted only the 315 fragments that have been previously designated to chromosomes (i.e., for Dmel, the four 316 chromosomes; and for SON and CAT the 39 biggest scaffolds), so as to run quality assessment 317 faster. We are aware that using a template assembly as a reference for SON may introduce biases 318 especially in terms of number of misassemblies, due to the evolutionary history of the 319 D. mojavensis populations (Matzkin, 2014) therefore the results must be considered carefully. 320 However, this provides a valid guide to make relative comparisons between assemblies created 321 here. Quast relies on MUMmer v3.23 (nucmer aligner v3.1; Kurtz et al., 2004) to align the assembly to the reference genome, and includes metrics and methods from the GAGE assessment 322 tool (Salzberg et al., 2012) and other tools. 323

324 Finally, assemblies were aligned to their reference genome using MUMmer4 (Marçais et al.,

325 2018) and plotted against the reference genome using Dot (https://github.com/dnanexus/dot).

326

327 2.6. Test of the *DBG2OLC* pipeline with Nanopore long-reads

We tested the DBG2OLC pipeline on *D. mojavensis* population Catalina using Nanopore longreads instead of PacBio long-reads with parameters optimized for SON: *Platanus* short-read assembler; *DBG2OLC* parameters MinOverlap 150; AdaptiveTh 0.020; KmerCov 2; MinLen 200; number of *Sparc* iterations 2 or 3 (both tested: P6r" vs. P6fr". For the *Canu* assembly, we used the correctedErrorRate = 0.055 since lower rates resulted in incomplete genome (0.039: 73.7 %; 0.045: 86.7 %; 0.055: 93.8 %). For the merged assembly, we used parameters as optimized for SON: the hybrid assembly as query; l = 1 Mb and lm = 10,000 bp (Table 3).

335

336 **3 RESULTS**

337 **3.1. DNA preparation**

The custom chloroform extraction led to a remarkable increase in the sizes of DNA fragments (light band between 30 and 120 Kb, right panel, Fig. 1) compared with standard extraction kits (left and middle panels, Fig. 1) for which the majority of fragments were shorter than 30 Kb. Long fragments in DNA libraries significantly increase DNA quantity output by PacBio sequencing (www.pacb.com).

343

344 **3.2.** Optimization of the DBG2OLC Pipeline

345 *3.2.1. Short-read assembler*

346 *Platanus* and *SparseAssembler* with a kmer size of 53 bp resulted in very similar assemblies; 347 SparseAssembler with a kmer size of 39 bp led to reduced contiguity; and applying two 348 successive rounds of SparseAssembler 53 bp-Kmer size did not improve the short-read assembly. 349 In the final merged assemblies, the use of *SparseAssembler* always led to slight decrease in 350 contiguity (comparing P3 to S3 and P6 to S6 for both Dmel and SON, Table 4). 351 SparseAssembler slightly reduced error rates but also BUSCO scores for Dmel, with limited effects for SON (Fig. 3B). We also observed that differences in P6 and S6 for SON mainly 352 353 resided in highly repetitive regions.

354

355 3.2.2. DBG2OLC parameters

We varied the DBG2OLC parameters MinOverlap, AdaptiveTh, KmerCovTh and MinLen to simultaneously optimize the contiguity and quality of the final assembly. Misassemblies created during the first steps of the hybrid assemblies were overall not resolved later, which makes that step key to the optimization. P0 corresponds to the reference set of parameters used in Chakraborty et al. (2016).

361

MinOverlap had a major effect on final assemblies, with a major improvement of contiguity (reduced number of fragments, increased N50, increased length of longest fragment; Fig. 3A,C) and of accuracy (reduced number of global and local misassemblies, reduced number of mismatches and indels; Fig. 3B, 3D) as seen in the P0 vs. P3 and P1 vs. P6 comparisons. This came at a cost of a slight decrease in BUSCO score for Dmel but not SON. Only an increase of MinOverlap up to 150 (the maximum recommended value for more than 50x coverage of PacBio reads) led to an optimal lower number of misassemblies (P2 vs. P6).

369

AdaptiveTh had little influence, except when MinOverlap was kept low: it decreased contiguity
and accuracy (P2 vs. P0). For assemblies with high MinOverlap, we found that P3 was less
fragmented than P4, P5 or P6 for SON and P4 was the least fragmented for Dmel. P6 was the

best compromise between contiguity and accuracy for SON, with the highest BUSCO score. P4 was the best compromise and with the highest BUSCO score for Dmel. Although coverage in both Illumina short-reads and PacBio long-reads was lower in SON than Dmel (Table 1), the quality of PacBio long-reads was higher (longer reads thanks to DNA extraction protocol, and more recent PacBio technology), which might have facilitated the better results with the more stringent AdaptiveTh.

- High KmerCovTh values resulted in major global misassemblies in SON (assessed with Mummer plots, not shown), with the largest fragment longer than the theoretical longest fragment in the Reference assembly (P4y vs. P4 and P6y,x vs. P6). It also caused a slight increase in error rates and a slight decrease in BUSCO score. In Dmel, no major global misassembly was detected, however error rates were higher and BUSCO scores slightly lower. We recommend to use KmerCovTh = 2, especially when using high AdaptiveTh. Using ContigTh = 1 had similar effects (major global misassemblies; P6g vs. P6 for SON) than high KmerCovTh values.
- 387

379

Increased MinLen from 200 to 2,000 resulted in a slight increase in contiguity for both Dmel and
 SON (PX vs. PXa). Error rates and BUSCO scores were not notably different, unless MinLen
 was increased up to 5,000 in which too many reads were parsed out, leading to higher error rates.

- 392 Increasing the number of *Sparc* iterations from 2 to 3 allowed a higher contiguity of large393 fragments, although with little effect on overall statistics.
- 394

The following parameters were used throughout the next optimization step: short-read assembler: *Platanus*; MinOverlap 150; AdaptiveTh 0.020 for SON, 0.010 for Dmel; KmerCov 2; MinLen
200 ; ContigTh 0; and number of *Sparc* iterations 3.

398

399 *3.2.3. Canu parameters*

Increasing correctedErrorRate from 0.039 to 0.055 slightly increased contiguity of the merged
assembly (P4q vs. P4r for Dmel and P6q vs. P6r for SON; Table 5). However, it also increased
error rates overall, and decreased the BUSCO complete genes score, especially for SON.

403

404 3.2.4. Quickmerge parameters

405 Parameters used in *Quickmerge* are shown in Table 3, and results in Table 5. Using the long-read 406 assembly as the Query assembly resulted in a strong decrease in contiguity compared with the 407 opposite (P4s vs. P4q for Dmel and P6s vs. P6q for SON). It also considerably increased error 408 rates for both species, and slightly decreased BUSCO complete gene score for SON.

409

We also tested the impact of the I and Im parameters. Using low Im with high I resulted in
identical assemblies (P4p vs. P4 for Dmel and P6p vs. P6 for SON) since backbones were already
parsed out due to high Im. Also, using Im = N50 or I = N50/2 resulted in identical assemblies
for Dmel. Otherwise, decreasing I resulted in lower number of fragments but higher error rates.
However, using a too high Im value would prevent smaller fragments from being merged.

415

416 *3.2.5. Polishing*

Polishing with both Quiver/Arrow and Pilon did not affect the contiguity (number of fragments, N50, and largest fragment; Table 6, Fig. 3) for either species. Conversely, it significantly reduced the number of indels on hybrid, long-read and merged assemblies. The number of mismatches was also reduced to a lesser extent. One drawback was the increase in number of misassemblies, except for the merged assembly. Finally, polishing increased the BUSCO score, especially on the hybrid assembly.

423

424 **3.3.** Test of the *DBG2OLC* pipeline with Nanopore long-reads

425 Compared with Miller et al. (2018), the CAT merged assembly was more contiguous and with a 426 higher BUSCO score, but with higher error rates (Table 5, P6r" vs. Ref. Miller), likely due to the 427 multiple polishing steps performed by Miller et al. (2018). Also note that we used raw, 428 uncorrected Nanopore reads for the CAT hybrid assembly similar to the SON hybrid assembly 429 with raw PacBio reads. Read correction prior to the hybrid assembly might help reduce error 430 rates (e.g., using the Nanopore basecall *Guppy* algorithm; Wick, Judd & Holt, 2019). Compared 431 with SON, CAT assemblies were less contiguous but with higher BUSCO scores (CAT-P6r" vs.

432 SON-P6n" and CAT-P6fr" vs. SON-P6fn"). The assignments of SON-P6fn" scaffolds to Muller
433 elements can be found in Supporting Information S1.

434 435

436 4 DISCUSSION

437 4.1. Optimized DBG2OLC pipeline

We performed an optimization of the *DBG2OLC* pipeline at each step, using both the model
species *D. melanogaster* and a non-model cactophilic *Drosophila*, *D. mojavensis* (population
Sonora). Based on our analysis, we make the following recommendations:

441

442 First, we were able to replicate the results by Chakraborty et al. (2016): our PO assembly had 443 similar contiguity as theirs with ~100x coverage although with lower error rates. The short-read 444 assembler had little impact, but we recommend using *Platanus*, which is especially designed for genomes with high level of heterozygosity (Kajitani et al., 2014), and this is more likely in non-445 446 model organisms that have not been raised for many generations in the laboratory. Based on 447 Quast results and BUSCO scores, we found the following parameter to be optimal on our 448 assembly for *D. mojavensis*: MinOverlap 150; AdaptiveTh 0.020; KmerCov 2; MinLen 200; 449 ContigTh 0; number of Sparc iterations 3 (SON assembly "P6fn"). We also tested these 450 parameters on the genomes of the other two D. mojavensis populations (from Baja California and 451 Mojave Desert) and of two sibling species, D. arizonae and D. navojoa (unpublished data L. 452 Matzkin), and found that the most stringent value for MinOverlap and AdaptiveTh lead to the best results, although AdaptiveTh had a smaller impact and its value may be safely reduced to 453 454 0.010, to be adjusted based on PacBio coverage. With these two parameters set to high values, we recommend to not increase KmerCovTh, MinLen and ContigTh since this would result in 455 456 too many long-reads parsed out and we observed major misassemblies. Conversely, increasing Sparc iterations, which is supposed to reduce the number of chimeras, had no negative effect. 457 458 We found that with high PacBio reads coverage, it is best to use the *Canu* correctedErrorRate 459 as low as possible, to 0.039. This increases the contiguity and decreases errors in the long-read 460 only assembly. However, this is not always possible, and can cause the genome size to be shorter than expected, as observed with the Nanopore reads. Finally, and similarly to Chakraborty et al. 461

(2016), we recommend to use the hybrid assembly as query and to adjust the *Quickmerge*parameter I to an intermediate value of 1 Mb, to prevent too many chimeric scaffolds while
allowing smaller fragments to be merged. Note that BUSCO scores and general statistics can
always be calculated even in absence of a reference genome of a closely related species.

467 4.2. Benefits of using the *DBG2OLC* pipeline and demonstration of effectiveness on a non468 model species

469 By merging hybrid and long-read only assemblies, we considerably increased the contiguity 470 compared with that of the hybrid assembly or the long-read only assembly (Table 6, Fig. 3), as 471 shown in Chakraborty et al. (2016). Also, error rates were lower than the long-read assembly, especially for Dmel. To obtain such low error rates with long-read data only, a higher coverage 472 473 would have been necessary representing a significant increase in sequencing cost (discussed in Chakraborty et al., 2016). For this study the D. mojavensis Illumina sequencing was performed 474 in 2011, if using current sequencing core prices it will total ~ \$178 (PE 150 HiSeq lane ~\$1,300 475 476 [only 1/12th of a lane needed for the 160 Mb D. mojavensis genome]; quality control of library 477 \$15; library preparation \$50-\$400 [depending if done in-house or by a core]). The PacBio sequencing was performed using a Sequel system, totaling 3,190 (library preparation 495×2 478 479 libraries; SMRT cells $1,100 \times 2$). Given the recent release of PacBio's Sequel II system the cost 480 for a similar amount of long-reads would be approximately ~\$740 (library preparation ~\$450, SMRT cell \$1,750 [would only need 1/6th of a cell for *D. mojavensis*]), therefore the *de novo* 481 482 assembly described in this study could be built for less than \$1,000.

483

466

484 One major improvement of the merged assembly (P6fn") in SON is that the 2q⁵ inversion in the 485 Muller element E (described in Ruiz, Heed & Wasserman, 1990) is now resolved, with the two 486 breakpoints clearly bridging the three chromosome parts (Fig. 4). This was not the case in the 487 hybrid assembly or the long-read only assembly (not shown). The Muller elements B, D and E in 488 our merged assembly P6fn" are in one piece and correspond to 99.24%, 99.11% and 96.67% 489 respectively of the corresponding chromosomes in the CAT reference genome. The Muller 490 element C was composed of three pieces in P6fn" accounting for 99.94% of the length of the 491 Muller element C in the CAT reference, and the Muller element A was more fragmented, as is

also the case in the CAT reference genome and all fragment lengths summed up to 94.77% of the
total size in the AT reference. However, in the CAT reference genome, D was in two fragments
that were joined in our assembly.

495

496 **4.3. Conclusion**

497 In the not too distant past genomic analysis was limited to just a set of a few model laboratory 498 species. Although this has led to unprecedented advances in our understanding of genetics and 499 genomics, in many instances such studies lacked an ecological context. Genome assemblies of 500 non-model species tended to be more fragmented or tended to be built using a genome from a 501 related model species, which is problematic if interested in trait mapping or genome structure evolution. Current sequencing and computational advancements have liberated our dependence 502 503 on classical laboratory model species. Here we have outlined a widely applicable computational 504 pipeline and sets of parameters to facilitate the construction of chromosome or nearlychromosome level genomic assemblies in a non-model species. Our PacBio merged assembly 505 performed better than using Nanopore reads, but more work is still needed to assess any 506 507 differences across multiple species, especially with newer advances to the sequencing platforms. Although it would be ideal to have a single set of parameters that would produce chromosome-508 509 level assemblies in all species, genomes are different. Ultimately the most optimal assembly 510 strategy would likely be to create a number of assemblies using multiple parameters, assessing their performance and possibly combining parts of assemblies. 511

512

513 **5 ACKNOWLEDGEMENTS**

We would like to thank Danny Miller for providing Nanopore data and scripts. We would like to thank Rod Wing, David Kudrna and Jayson Talag at the Arizona Genomics Institute for their assistance in the PacBio sequencing. This work was supported by funding from the National Science Foundation (IOS-1557697) to LMM and the University of Arizona to LMM as well as through a Fellowship from the Fyssen Fundation to CCJ.

519

520 6 REFERENCES

- [dataset] Allan, C. W., & Matzkin, L. M. (2019) Genomic analysis of the four ecologically
 distinct cactus host populations of *Drosophila mojavensis*. NCBI. PRJNA530196.
- Allan, C. W., & Matzkin, L. M. (2019) Genomic analysis of the four ecologically distinct cactus
 host populations of *Drosophila mojavensis*. *BMC Genomics*, 20(1), 732.
 doi:10.1186/s12864-019-6097-z
- 526 Bao, E & Lan, L (2017) HALC: High throughput algorithm for long read error correction. *BMC* 527 *Bioinformatics*, 18, 204.
- Benowitz, K. M., Coleman, J. M., & Matzkin, L. M. (2019). Assessing the Architecture of
 Drosophila mojavensis Locomotor Evolution with Bulk Segregant Analysis. G3-Genes
 Genomes Genetics, 9(5), 1767-1775. doi:10.1534/g3.119.400036
- Bentley, D. R., Balasubramanian, S., Swerdlow, H. P., Smith, G. P., Milton, J., Brown, C. G., ...
 & Smith, A. J. (2008) Accurate whole human genome sequencing using reversible
 terminator chemistry. *Nature* 456,:53-59.
- Bono, J. M., Matzkin, L. M., Kelleher, E. S., & Markow, T. A. (2011). Postmating transcriptional
 changes in reproductive tracts of con- and heterospecifically mated *Drosophila mojavensis*females. *Proceedings of the National Academy of Science*, 108(19), 7878-7883.
- 537 doi:10.1073/pnas.1100388108
- 538 Carvalho, A. B., Dupim, E. G. & Goldstein, G. (2016) Improved assembly of noisy long reads by
 539 k-mer validation. *Genome Research*, *26*, 1710-1720.
- 540 Chakraborty, M., Baldwin-Brown, J. G., Long, A. D. & Emerson, J. J. (2016) Contiguous and
 541 accurate de novo assembly of metazoan genomes with modest long read coverage. *Nucleic*542 *Acids Research*, 44, e147.
- 543 Chin, C.-S., Alexander, D. H., Marks, P., Klammer, A. A., Drake, J., Heiner, C., ... & Korlach, J.
 544 (2013) Nonhybrid, finished microbial genome assemblies from long-read SMRT
 545 sequencing data. *Nature Methods*, *10*, 563-569.

- 546 Coleman, J. M., Benowitz, K. M., Jost, A. G. & Matzkin, L. M. (2018) Behavioral evolution
 547 accompanying host shifts in cactophilic *Drosophila* larvae. *Ecology & Evolution*, *8*, 6921548 6931.
- 549 Drosophila 12 Genomes Consortium. (2007) Evolution of genes and genomes on the *Drosophila*550 phylogeny. *Nature*, 450, 203-218.
- 551 Ellegren, H. (2014) Genome sequencing and population genomics in non-model organisms.
 552 *Trends in Ecology & Evolution*, 29, 51-63.
- Grüning, D., Dale, R., Sjödin, A., Chapman, B. A., Rowe, J., Tomkins-Tinch, C. H., Valieris, R.,
 Köster, J. & The Bioconda Team (2018) Bioconda: sustainable and comprehensive
 software distribution for the life sciences. Nature Methods, 15,475-476.
- Gurevich, A., Saveliev, V., Vyahhi, N. & Tesler, G. (2013) QUAST: quality assessment tool for
 genome assemblies. *Bioinformatics*, *29*, 1072.
- 558 Heed, W. B. (1978). Ecology and genetics of Sonoran desert *Drosophila*. In P. F. Brussard (Ed.),
 559 Ecological genetics: The interface (pp. 109-126): Springer-Verlag.
- Holt, J. M., Wang, J. R., Jones, C. D. & McMillan, L. (2016) Improved long read correction for
 de novo assembly using an FM-index. *BioRxiv*.
- 562 Hu, R., Sun, G. & Sun, X. (2016) LSCplus: a fast solution for improving long read accuracy by
 563 short read alignment. *BMC Bioinformatics*, *17*, 451.
- Kajitani, R., Toshimoto, K., Noguchi, H., Toyoda, A., Ogura, Y., Okuno, ... & Itoh, T. (2014)
 Efficient *de novo* assembly of highly heterozygous genomes from whole-genome shotgun
 short reads. *Genome Research*, 24, 1384-1395.
- 567 Kim, K. E., Peluso, P., Babayan, P., Yeadon, P. J., Yu, C., Fisher, W. W., ... & Landolin, J. M.
 568 (2014) Long-read, whole-genome shotgun sequence data for five model organisms.
 569 *Scientific Data*, *1*, 140045.
- Koren, S., Walenz, B. P., Berlin, K., Miller, J. R., Bergman, N. H. & Phillippy, A. M. (2017)
 Canu: scalable and accurate long-read assembly via adaptive k-mer weighting and repeat
 separation. *Genome Research*, *27*, 722-736.

573 Kurtz, S., Phillippy, A., Delcher, A. L., Smoot, M., Shumway, M., Antonescu, C. & Salzberg, S.
574 L. (2004) Versatile and open software for comparing large genomes. *Genome Biology*, *5*,
575 R12.

576 Langmead, B., Trapnell, C., Pop, M. & Salzberg, S. L. (2009) Ultrafast and memory-efficient
577 alignment of short DNA sequences to the human genome. *Genome Biology*, *10*, R25.

- Marçais, G., Delcher, A. L., Phillippy, A. M., Coston, R., Salzberg, S. L. & Zimin, A. (2018)
 MUMmer4: A fast and versatile genome alignment system. *PLOS Computational Biology*, *14*, e1005944.
- Matzkin, L. M., Watts, T. D., Bitler, B. G., Machado, C. A., & Markow, T. A. (2006). Functional
 genomics of cactus host shifts in *Drosophila mojavensis*. *Molecular Ecology*, 15, 46354643.
- 584 Matzkin, L. M. (2014). Ecological genomics of host shifts in *Drosophila mojavensis*. Advances in
 585 *Experimental Medicine and Biology*, 781, 233-247.
- 586 Miclotte, G., Heydari, M., Demeester, P., Rombauts, S., Van de Peer, Y., Audenaert, P. &
 587 Fostier, J. (2016) Jabba: hybrid error correction for long sequencing reads. *Algorithms for*588 *Molecular Biology*, 11, 10.
- 589 Miller, D. E., Staber, C., Zeitlinger, J. & Hawley, R. S. (2018) Highly contiguous genome
 590 assemblies of 15 *Drosophila* species generated using Nanopore sequencing. *G3: Genes,*591 *Genomes, Genetics,* 8: 3131-3141.
- 592 [dataset] Miller, D. E., Staber, C., Zeitlinger, J. & Hawley, R. S. (2018) WGS of *Drosophila* 593 *mojavensis* males from stock 15081-1352.22. NCBI. SRR6425997.
- Miller, D., Smith, C. B., Hawley, R. S. & Bergman, C. M. (2013) PacBio whole genome shotgun
 sequences for the *D. melanogaster* reference strain. http://bergmanlab.genetics.uga.edu.
- 596 [dataset] Miller, D., Smith, C. B., Hawley, R. S. & Bergman, C. M. (2013) PacBio whole genome
 597 shotgun sequences for the *D. melanogaster* reference strain. NCBI. PRJNA237120

598 Rhoads, A. & Au, K. F. (2015) PacBio sequencing and its applications. *Genomics, Proteomics & Bioinformatics*, 13, 278-289.

Rudman, S. M., Barbour, M. A., Csilléry, K., Gienapp, P., Guillaume, F., Hairston, Jr. N. G., ...
& Levine, J. M. (2018) What genomic data can reveal about eco-evolutionary dynamics. *Nature Ecology & Evolution*, *2*, 9-15.

Ruiz, A., Heed, W. B. & Wasserman, M. (1990) Evolution of the *mojavensis* cluster of
cactophilic *Drosophila* with descriptions of two new species. *Journal of Heredity*, *81*, 3042.

Salmela, L. & Rivals, E. (2014) LoRDEC: accurate and efficient long read error correction. *Bioinformatics*, *30*, 3506-3514.

Salzberg, S. L., Phillippy, A. M., Zimin, A., Puiu, D., Magoc, T., Koren, S., ... & Yorke, J. A.
(2012) GAGE: A critical evaluation of genome assemblies and assembly algorithms. *Genome Research*, 22, 557-567.

Schaeffer, S. W., Bhutkar, A., McAllister, B. F., Matsuda, M., Matzkin, L. M., O'Grady, P. M., . .
Kaufman, T. C. (2008). Polytene Chromosomal Maps of 11 *Drosophila* Species: The
Order of Genomic Scaffolds Inferred From Genetic and Physical Maps. Genetics, 179(3),
1601-1655. doi:10.1534/genetics.107.086074

615 Simpson, J. T., Workman, R. E., Zuzarte, P. C., David, M., Dursi, L. J. & Timp, W. (2017)

616 Detecting DNA cytosine methylation using nanopore sequencing. *Nature Methods*, 14, 407.

- 617 SMRT (Link v4.0.0) SMRT Link v4.0.0 Pacific Biosciences SMRT Tools Reference Guide.
 618 http://www.pacb.com/support/software-downloads/.
- 619 Thurmond, J., Goodman, J. L., Strelets, V. B., Attrill, H., Gramates, L. S., Marygold, S. J., ... &
 620 the FlyBase Consortium. (2019) FlyBase 2.0: the next generation. *Nucleic Acids Research*,
 621 47, D759-D765.
- [dataset] University of Manchester. (2015). Whole genome shotgun sequences for ISO1 and nos gal4;UAS-DCR2 laboratory strains of *Drosophila melanogaster*. EMBL-ENA.
 ERX645969
- Urban, J. M., Bliss, J., Lawrence, C. E. & Gerbi, S. A. (2015) Sequencing ultra-long DNA
 molecules with the Oxford Nanopore MinION. *bioRxiv*.

627	Walker, B. J., Abeel, T., Shea, T., Priest, M., Abouelliel, A., Sakthikumar, S., & Earl, A. M.
628	(2014) Pilon: an integrated tool for comprehensive microbial variant detection and genome
629	assembly improvement. PLOS ONE, 9, 1-14.
630	Waterhouse, R. M., Seppey, M., Simão, F. A., Manni, M., Ioannidis, P., Klioutchnikov, G.,
631	Kriventseva, E. V. & Zdobnov, E. M. (2017) BUSCO applications from quality
632	assessments to gene prediction and phylogenomics. Molecular Biology and Evolution, 35,
633	543-548; https://busco.ezlab.org/.
634	Wick, R. R., Judd, L. M. & Holt, K. E. (2019) Performance of neural network basecalling tools
635	for Oxford Nanopore sequencing. Genome Biology, 20, 129.
636	Xiao, CL., Chen, Y., Xie, SQ., Chen, KN., Wang, Y., Han, Y., Luo, F. & Xie, Z. (2017)
637	MECAT: fast mapping, error correction, and de novo assembly for single-molecule
638	sequencing reads. Nature Methods, 14, 1072-1074.
639	Ye C Hill C M Wu S Ruan J & Ma Z S (2016) DBG2OLC: Efficient assembly of large
640	genomes using long erroneous reads of the third generation sequencing technologies.
641	Scientific Reports, 6, 31900.
642	Ye, C, & Ma, Z, S. (2016) Sparc: a sparsity-based consensus algorithm for long erroneous
643	sequencing reads. <i>PeerJ</i> , <i>4</i> , e2016.
644	Ye C Ma Z S Cannon C H Pop M & Yu D W (2012) Exploiting sparseness in <i>de novo</i>
645	genome assembly. <i>BMC Bioinformatics</i> . 13. S1.
646	
040	
647	
648	
649	
650	
651	7 ΝΑΤΑ ΑΥΑΠ ΑΒΗ ΙΤΥ
031	
Y	
· · · · · · · · · · · · · · · · · · ·	

This article is protected by copyright. All rights reserved

Raw PacBio reads are available at NCBI's SRA (https://www.ncbi.nlm.nih.gov/sra) under
BioProject accession number PRJNA573111. The *D. mojavensis* final assembly P6fn" is
available at OSF (doi.org/10.17605/OSF.IO/pvbde).

655

660

656 8 AUTHOR CONTRIBUTION

657 CCJ, CWA and LMM reviewed the literature and selected the pipeline. CWA performed DNA
658 extraction. CCJ performed the bioinformatics work with the help of CWA. CCJ wrote the
659 manuscript with contributions from LMM and CWA.

Tables

663

669

670

662

664 Table 1. Sequencing technology and coverage of each data set.

Organism	Genome size	Sequencing technology	Data output	Coverag
Drosophila	~ 140 Mb	Illumina HiSeq 2000	16.8 Gb ^a	120x
melanogaster				
		PacBio RS II	16.1 Gb ^b	115x
Drosophila	~ 160 Mb	Illumina HiSeq 2500		
<i>mojavensis</i> (Sonora)		100 bp paired ends	10.1 Gb ^a	63x
		2,500 bp mate pairs	5.9 Gb ^c	37x
		PacBio Sequel	10.4 Gb ^b	65x
Drosophila	~ 160 Mb	Illumina NextSeq 500		
<i>mojavensis</i> (Catalina)		150 bp paired ends	9.1 Gb ^a	55x
		Oxford Nanopore MinION	15.2 Gb	95x

^b calculated as the total number of bases in data files obtained from converting .bax.h5 files into .bam files, and

667 converting the obtained subreads.bam files into fasta files, with no specific trimming

668 ^c calculated as the total number of bases in data files after trimming from *Platanus_internal_trim*.

Table 2. *DBG2OLC* parameters.

							Number of	
A	ssembly	Assembler	MinOverlap	AdaptiveTh	MinLen	KmerCovTh	<i>Sparc</i> iterations	ContigTh
P	0	Platanus	20	0.002	200	2	2	1
P	1	Platanus	20	0.020	200	2	2	1
P2	2	Platanus	100	0.020	200	2	2	1
P3	3	Platanus	150	0.002	200	2	2	1
Sa	3	SparseAssembler	150	0.002	200	2	2	1
P4	4	Platanus	150	0.010	200	2	2	1
P4	4f	Platanus	150	0.010	200	2	3	1
P4	4g	Platanus	150	0.010	200	2	3	2
P.	5	Platanus	150	0.015	200	2	2	1
Pe	6	Platanus	150	0.020	200	2	2	1
Pe	6f	Platanus	150	0.020	200	2	3	1
Pe	бg	Platanus	150	0.020	200	2	3	2
Se	6	SparseAssembler	150	0.010	200	2	2	1
P4	4a	Platanus	150	0.010	2000	2	2	1
P:	5a	Platanus	150	0.015	2000	2	2	1
Pe	6a	Platanus	150	0.020	2000	2	2	1
Pe	6b	Platanus	150	0.020	5000	2	2	1
P2	4y	Platanus	150	0.010	200	10	2	1
Pe	бу	Platanus	150	0.020	200	10	2	1
Pe	6x	Platanus	150	0.020	200	5	2	1

672 673

This article is protected by copyright. All rights reserved

671

Species	Assembly	Canu		Merge parameters	
		correctedErrorRate	Query assembly	l (bp)	lm (bp)
	P4	0.039	Hybrid	N50: 10,000,000	10,000
	P4f	0.039	Hybrid	N50: 10,000,000	10,000
	P4n	0.039	Hybrid	N50/2: 5,000,000	10,000
	P4o	0.039	Hybrid	N50/4: 2,500,000	10,000
Dru al	P4o"	0.039	Hybrid	1,000,000	10,000
Dmei	P4fo"	0.039	Hybrid	1,000,000	10,000
	P4p	0.039	Hybrid	N50: 10,000,000	0
	P4q	0.039	Hybrid	0	0
	P4r	0.055	Hybrid	0	0
	P4s 0.039		Long-read	0	0
	P6 0.039		Hybrid	N50: 2,600,000	10,000
	P6f	0.039	Hybrid	N50: 2,600,000	10,000
	P6n	0.039	Hybrid	N50/2: 1,300,000	10,000
	P6n"	0.039	Hybrid	1,000,000	10,000
SON	P6fn"	0.039	Hybrid	1,000,000	10,000
SON	P60	0.039	Hybrid	N50/4: 0,650,000	10,000
	Рбр	0.039	Hybrid	N50: 2,600,000	0
	P6q	0.039	Hybrid	0	0
	P6r	0.055	Hybrid	0	0
	P6s	0.039	Long-read	0	0
САТ	P6r"	0.055	Hybrid	1,000,000	10,000
UTI	P6fr"	0.055	Hybrid	1,000,000	10,000

674 Table 3. *Canu* and *Quickmerge* parameters.

		#		Largest	st # global	l # local #	# Mismatches	# Indels	BI	USCO score (%	b)
Species	Assembly	" Fragments	N50 (bp)	fragment	misassemblies	misassemblies	per 100 Kb	(per 100	complete	fragmented	missing
		0		size (bp)			L	Kb	genes	genes	genes
	P0	792	16,084,532	25,835,722	2,356	1,001	12.62	9.51	98.11	0.57	1.32
	P1	900	16,023,660	24,892,400	2,656	1,027	11.82	9.55	97.32	0.61	2.07
	P2	292	21,449,278	24,867,057	1,076	371	10.27	7.35	97.07	0.64	2.07
	P3	282	19,409,490	25,811,113	890	370	10.68	6.57	97.21	0.50	2.29
	S3	314	19,674,671	24,895,732	771	312	10.03	7.03	95.64	0.79	3.57
	P4	266	21,413,354	25,775,485	623	267	8.66	6.49	98.75	0.57	0.68
	P4f	267	21,413,185	25,776,014	919	318	10.55	6.73	98.75	0.57	0.68
	P4g	227	21,412,816	25,796,604	667	263	10.05	6.47	98.39	0.57	1.04
Dmel	P5	268	19,684,947	25,810,399	882	323	10.19	6.95	97.11	0.57	2.29
	P6	261	21,455,994	24,861,269	801	289	10.65	7.02	97.11	0.64	2.25
	S6	290	19,674,784	24,911,291	726	331	10.19	6.84	95.39	0.82	3.79
	P4a	267	21,414,759	25,777,026	920	338	10.79	6.94	98.75	0.57	0.68
	P5a	270	19,684,947	25,810,399	892	323	10.19	6.95	97.11	0.61	2.29
	P6a	258	21,455,918	24,861,450	553	282	9.11	6.36	97.11	0.64	2.25
	P6b	259	21,455,964	24,861,284	785	295	10.37	6.90	97.11	0.64	2.25
	P4y	239	21,413,104	25,789,761	633	304	10.43	6.83	98.71	0.57	0.71
	P6x	257	21,450,514	24,861,357	777	324	10.64	7.08	97.11	0.64	2.25

Table 4. DBG2OLC parameter optimization: contiguity and accuracy. Assemblies refer to parameter sets defined in Table 2.

		Рбу	242	21,455,993	24,861,357	610	298	9.15	6.35	97.03	0.64	2.32
		Ref. genome	7	25,286,936	32,079,331	NA	NA	NA	NA	98.68	0.75	0.57
		Ref. Chakraborthy et al. (P0)	NA	~23 Mb	NA	~5,500	~3,300	~18	130	NA	NA	NA
		P0	348	28,767,831	34,246,767	8,244	10,064	328.42	265.12	98.39	0.86	0.75
		P1	495	21,851,486	34,252,641	9,066	10,330	329.18	266.49	98.39	0.82	0.79
		P2	132	27,067,002	33,145,725	7,351	9,756	326.40	264.27	98.25	0.96	0.79
		P3	80	27,092,095	34,236,744	7,189	9,670	325.21	263.71	98.25	1.00	0.75
		\$3	90	18,984,317	34,265,435	7,214	9,687	324.97	262.72	98.36	0.93	0.71
		P4	92	27,081,921	33,130,663	7,166	9,688	324.99	264.24	98.21	1.04	0.75
		Р5	97	27,073,333	34,231,430	7,327	9,782	324.58	263.90	98.36	0.89	0.75
Q	SON	P6	104	27,074,084	33,145,389	7,168	9,753	324.69	264.16	98.39	0.93	0.68
	2011	P6f	103	27,125,966	33,144,936	7,173	9,760	324.80	264.49	98.36	0.96	0.68
		P6g	80	27,068,405	37,117,163	7,151	9,759	324.58	267.38	98.39	0.96	0.64
		S6	119	11,627,144	33,084,645	7,280	9,737	324.83	263.96	98.25	1.00	0.75
		P4a	88	27,072,608	34,217,177	7,255	9,736	324.67	263.74	98.32	0.89	0.79
\mathbf{O}		P5a	97	27,081,858	34,230,744	7,391	9,750	324.72	264.10	98.36	0.96	0.68
\mathbf{C}		Рба	104	27,124,465	33,144,017	7,179	9,761	325.07	264.57	98.43	0.89	0.68
		P6b	98	27,089,768	34,232,191	7,237	9,755	324.76	264.37	98.39	0.93	0.68
		P4y	98	27,058,011	37,135,015	7,391	9,798	324.25	267.26	98.29	1.04	0.68

Article

 P6x	99	27,066,010	33,076,049	7,211	9,740	324.72	263.24	98.32	0.89	0.79
Рбу	100	27,061,534	37,152,367	7,168	9,753	324.56	267.59	98.32	1.00	0.68
Ref.	39	26,426,104	33,738,561	NA	NA	NA	NA	98.14	0.93	0.93

679 Table 5. *Canu* and *Quickmerge* parameter optimization: contiguity and accuracy. Assemblies refer to parameter sets defined in 680 Table 3.

		#		Largest	# global	# local	# Mismatchas	# Indols		BUSCO score	
Species	Assembly	^{<i>π</i>} Fragments	N50 (bp)	fragment size (bp)	misassemblies	misassemblies	per 100 Kb	per 100 Kb	complete genes	fragmented genes	missing genes
	P4	266	21,413,354	25,775,485	623	267	8.66	6.49	98.75	0.57	0.68
	P4f	267	21,413,185	25,776,014	919	318	10.55	6.73	98.75	0.57	0.68
	P4o	265	21,413,352	25,775,437	635	275	8.57	6.42	98.75	0.57	0.68
	P4o"	210	21,413,344	25,775,300	638	295	8.10	6.02	98.79	0.57	0.64
Dmel	P4fo"	211	21,413,185	25,776,408	943	340	9.90	6.20	98.79	0.57	0.64
	P4q	116	21,413,360	25,775,323	1,561	521	8.72	5.77	98.79	0.57	0.64
	P4r	113	21,450,483	25,801,485	1,751	582	8.66	5.75	98.61	0.75	0.64
	P4s	338	14,528,003	25,770,616	3,684	1,145	12.34	7.34	98.79	0.57	0.64
	Ref.	7	25,286,936	32,079,331	NA	NA	NA	NA	98.68	0.75	0.57
	P6	104	27,074,084	33,145,389	7,168	9,753	324.69	264.16	98.39	0.93	0.68
1	P6f	103	27,125,966	33,144,936	7,173	9,760	324.80	264.49	98.36	0.96	0.68
	P6n	88	27,074,290	33,145,104	7,357	9,788	324.44	263.58	98.39	0.93	0.68
SON	P6n"	67	27,074,601	33,145,127	7,261	9,728	325.29	263.80	98.29	0.96	0.75
	P6fn"	66	27,125,795	33,144,975	7,271	9,727	325.23	263.97	98.25	1.00	0.75
	P60	65	27,074,498	33,145,149	7,261	9,718	325.17	263.76	98.32	0.93	0.75
	P6q	62	27,074,467	33,145,189	7,470	9,752	325.83	263.63	98.32	0.93	0.75

	P6r	58	27,027,841	34,117,449	7,245	9,165	329.97	262.71	93.25	0.93	5.82
	P6s	151	27,122,727	34,181,614	9,159	10,205	328.59	263.06	98.14	0.93	0.93
	Ref.	39	26,426,104	33,738,561	NA	NA	NA	NA	98.14	0.93	0.9
	P6n"	79	12,454,906	23,097,599	2,272	3,104	56.41	67.39	98.39	1.00	0.61
	P6fn"	79	12,457,238	23,102,169	2,274	2,949	56.40	65.70	98.64	0.82	0.54
CAT	Ref.	39	26,866,924	34,148,556	NA	NA	NA	NA	98.11	0.93	0.96
	Ref.										
	Miller et	122	5.0 Mb	NA	NA	NA	0.22	0.052	98	NA	NA
	al. (2018)										

681 **Table 6. Improvement of contiguity and quality throughout the pipeline.** Abbreviations: Sr: short-read assembly; H: hybrid assembly;

682 Lr: long-read assembly; M: merged assembly; Q: Quiver polishing; P: Pilon polishing. Here MQP corresponds to P4 for Dmel and P6 for
683 SON (Tables 4, 5).

			#		Largest	# global	# [009]	# Mismatahas	# Indols		BUSCO score	
	Species	Assembly	# Fragments	N50 (bp)	fragment (bp)	misassemblies	misassemblies	per 100 kb	per 100 kb	complete genes	fragmented genes	missing genes
		Sr	15,404	22,245	250,600	138	22	3.05	0.68	96.96	2.07	0.96
	1	Н	302	5,369,803	20,351,387	449	391	28.34	570.44	66.02	15.51	18.47
		HQ	302	5,378,161	20,387,636	685	439	8.26	13.51	95.03	2.00	2.97
	Dmel	HQP	302	5,378,529	20,385,575	689	464	8.91	7.78	97.89	0.57	1.54
\mathbf{C}		Lr	426	10,086,116	24,845,957	3,935	2,126	16.25	12.16	89.03	6.50	4.47
		LrQP	426	10,090,934	24,862,005	4,002	2,131	12.23	8.07	98.21	0.57	1.21
		М	266	21,413,390	25,776,101	603	288	8.95	7.19	98.75	0.57	0.68

This article is protected by copyright. All rights reserved

Irticle

	MQP	266	21,413,354	25,775,485	623	267	8.66	6.49	98.75	0.57	0.68
	Ref.	7	25,286,936	32,079,331	NA	NA	NA	NA	98.68	0.75	0.57
	Sr	57,046	3,385	45,376	346	2,539	219.24	200.08	89.10	7.93	2.97
	Н	136	9,893,295	18,894,064	6,773	9,558	331.40	457.22	88.14	8.40	3.47
	HQ	136	9,840,048	18,808,757	6,898	9,646	324.72	271.29	98.54	0.93	0.54
	HQP	136	9,834,752	18,808,038	6,893	9,663	324.81	265.21	98.68	0.82	0.50
SON	Lr	343	2,678,315	8,942,850	8,790	9,912	332.66	316.57	96.57	1.93	1.50
	LrQP	343	2,679,816	8,945,441	9,055	10,035	328.02	262.04	98.14	1.04	0.82
	М	104	27,077,180	33,146,112	7,167	9,792	325.14	264.44	98.43	0.89	0.68
	MQP	104	27,074,084	33,145,389	7,168	9,753	324.69	264.16	98.39	0.93	0.68
	Ref.	39	26,426,104	33,738,561	NA	NA	NA	NA	98.14	0.93	0.9

685	Figure	legends

686

Fig. 1. Size profile of DNA from *D. mojavensis* (Sonora) extracted with three different methods.
Images of three gels, corresponding to each method, have been collated here, using the same ladder
(sizes shown on the left).
Fig. 2. DBG2OLC Pipeline, including the final merging step and the polishing steps

692

Fig. 3. Contiguity (A, D), error level (B, E) and Busco score (C, F) for Dmel (A-C) and SON (D-F)
assemblies, at each step of the pipeline. Significantly larger values are printed above dashed lines.
Assembly parameters are described in Table 6.

696

697 Fig. 4. Alignment of SON merged assembly P6fn" (y-axis) on the *D. mojavensis* (Catalina)

reference genome (x-axis). Only fragments longer than 900 Kb are shown. Muller elements
(chromosomes) of the reference genome (Catalina) are shown. Yellow boxes represent a single Muller
element. Gray horizontal lines indicate the contigs from the SON assembly. The assignments of
scaffolds to Muller elements can be found in Supporting Information S1.

702

703 Supporting information

704

Acc

705 **Table S1.** Assignments of scaffolds to Muller elements

100 · Busco score (% genes) 0 08 06 complete fragmented missing 60 HQ HQP Lr LrQP M MQP Sr н Assemblies

(F) SON - BUSCO score

fici 2 **Buted** 722

Catalina Island Reference Genome

723 Appendix. Command lines to call each program used in the study.

724

725 (1) Data manipulation

- 726 Merge .bam files from several PacBio sequencing cells (node=1:ncpus=1:mem=6gb):
- bamtools merge -list ListPBreadsFiles.fofn -out PBreads_all.bam
- 728 Merge two .fasta files: (node=1:ncpus=1:mem=6gb):
- 729 cat reads1.fasta reads2.fasta > reads1_and_2.fasta
- 730 Convert .bax.h5 to .bam (node=1:ncpus=1:mem=6gb):
- 731 bax2bam my_movie.*.bax.h5 -o my_movie
- 732 Convert .bam to .fastq (node=1:ncpus=1:mem=6gb):
- 733 samtools fastq my_reads.bam > my_reads.fastq
- 734 OR
- 735 _ bam2fastq my_reads.bam -o my_reads
- 736 Convert .bam to .fasta (node=1:ncpus=1:mem=6gb):
- 737 bam2fasta my_reads.bam -o my_reads
- 738 Convert .fastq to .fasta with the *prinseq-lite tool* (v0.20.4) (node=1:ncpus=1:mem=6gb):
- 739 perl prinseq-lite.pl -fastq my_reads.fastq -out_format 1
- 740 Convert .fastq to .fasta with the *FASTX* toolkit (v0.0.13) (node=1:ncpus=1:mem=6gb):
- 741 fastq_to_fasta -i my_reads.fastq -o my_reads.fasta

742

- 743 (2) Short-read assembly
- 744 Trimming (with *Platanus* trimmer)
- 745 (node=1:ncpus=5:mem=30gb;cput=10:00:00;walltime=02:00:00):
- 746 platanus_trim my_PE_reads_1.fastq my_PE_data_2.fastq -t 5
- 747 *Platanus* assembler (node=1:ncpus=14:mem=65gb; cput=28:00:00;walltime=02:00:00):
- 748 platanus assemble -o Shortread_contigs -f my_PE_reads_[12].fastq.trimmed -t 16 -m 75 2>
- 749 Plat_SON2.log

- 750 *SparseAssembler*, with kmer size 53 (node=1:ncpus=1:mem=6gb; cput=02:00:00;
- 751 walltime=02:00:00):
- 752 SparseAssembler LD 0 k 53 g 15 NodeCovTh 1 EdgeCovTh 0 GS 165000000 p1
- 753 my_PE_reads_1.fastq.trimmed p2 my_PE_reads_2.fastq.trimmed
- 754

755 *(3) Hybrid assembly*

- 756 *DBG2OLC* step (node=1:ncpus=1:mem=6gb; cput=02:50:00:walltime=02:50:00):
- 757 DBG2OLC k 17 KmerCovTh 2 MinOverlap 150 AdaptiveTh 0.002 LD1 0 MinLen 200 Contigs
- 758 Shortread_contigs.fasta RemoveChimera 1 f my_PBreads.fasta
- 759 Note: DBG2OLC has memory limitations. If run on node=1:ncpus=2:mem=12gb, it will still use
- 760 one chore only, but more memory as allowed, and run twice as fast.
- 761 Building list of contigs identifiers (node=1:ncpus=1:mem=6gb;
- 762 cput=00:05:00;walltime=00:05:00) (requires python2):
- 763 split_reads_by_backbone.py -b backbone_raw.fasta -o ./Cons_backbones -r
- 764 Shortread_contigs_and_PBreads.fasta -c DBG2OLC_Consensus_info.txt
- 765 *Sparc* step ((node=1:ncpus=28:mem=90gb; cput=84:00:00;walltime=03:00:00):
- 766 sh split_and_run_sparc_ncpus_new.sh ./Cons_backbones 2 28 > Sparclog_Part1.txt
- 767

768 (4) Long-read only assembly with Canu

- 769 canu -p PB_Only_Assembly -d /path_to_curr_dirr genomeSize=123m correctedErrorRate=0.039 -
- 770 useGrid=true -maxThreads=16 -maxMemory=90 -gridEngineThreadsOption="-I
- 771 select=1:ncpus=16:mem=100gb" -gridEngineMemoryOption="-I walltime=02:00:00" -gridOptions="-W
- 772 group_list=my_group_ID -q standard" -pacbio-raw /path_to_Pbreads/Pbreads.fasta
- 773 Note: Because the *Canu* pipeline calls a master script, more parameters, normally passed to the
- PBS script have to be sent to the command line when calling *Canu*. The option -nanopore-raw wasused when assembling Nanopore reads.
- 776

777 (5) Assembly merging

- Vising the *Quickmerge* wrapper, and with hybrid assembly as donor and long-read only assembly
 as acceptor (node=1:ncpus=1:mem=6gb; cput=00:25:00; walltime=00:25:00; requires python/3):
- 780 merge_wrapper.py Hybrid_assembly.fasta longread_assembly.fasta -I 10000000 -Im 10000
- 781

782 (6) Quiver polishing

- 783 Align PB reads (in .bam format) to assembly with *Pbalign* (node=1:ncpus=28:mem=168gb;
- 784 cput=224:00:00;walltime=08:00:00):
- 785 pbalign --nproc 28 my_PBreads.bam my_assembly.fasta aligned_PBreads.bam
- 786 Index aligned PB reads (node=1:ncpus=1:mem=6gb; cput=00:10:00;walltime=00:10:00):
- 787 pbindex aligned_PBreads.bam
- 788 Index assembly (node=1:ncpus=1:mem=6gb; cput=00:02:00;walltime=00:02:00):
- 789 samtools faidx my_assembly.fasta
- 790 Run Quiver (node=1:ncpus=28:mem=168gb; cput=154:00:00;walltime=05:30:00):
- 791 quiver -j 28 -r my_assembly.fasta -o my_assembly_polished.fasta aligned_PBreads.bam
- 792 Run Arrow (node=1:ncpus=28:mem=168gb; cput=154:00:00; walltime=05:30:00):
- 793 arrow -j 28 -r my_assembly.fasta -o my_assembly_polished.fasta aligned_PBreads.bam
- 794

795 (7) Pilon polishing

- 796 Index the assembly file (node=1:ncpus=6:mem=6gb; cput=00:05:00;walltime=00:05:00):
- 797 bowtie2-build my_assembly.fasta my_assembly
- Align short-reads to assembly with Bowtie2 (node=1:ncpus=28:mem=168gb;
- 799 cput=42:00:00;walltime=01:30:00):
- 800 bowtie2 -x my_assembly -1 my_PE_reads_1.fastq.trimmed -2 my_PE_reads_2.fastq.trimmed -S
- 801 Aligned_reads.sam -p 28
- 802 Convert .sam to .bam (node=1:ncpus=1:mem=6gb; cput=00:10:00;walltime=00:10:00):
- 803 samtools view -bS Aligned_reads.sam > Aligned_reads.bam
- 804 Sort reads (node=1:ncpus=28:mem=168gb; cput=07:00:00;walltime=00:15:00):
- 805 samtools sort Aligned_reads.bam -o Aligned_reads_sorted.bam -@ 28

806	Index reads (node=1:ncpus=6:mem=6gb; cput=00:02:00;walltime=00:02:00):
807	samtools index Aligned_reads_sorted.bam -@ 28
808	Run <i>Pilon</i> with paired ends only (node=1:ncpus=28:mem=168gb;
809	cput=14:00:00;walltime=00:30:00; requires java/8):
810	java -Xmx64G -jar pilon-1.22.jargenome my_assembly.fastafrags Aligned_PEreads_sorted.bam
811	output ./my_assembly_polishedthreads 28
812	Run Pilon with paired ends and mate pairs
813	(node=1:ncpus=28:mem=168gbcput=28:00:00;walltime=01:00:00; requires java/8):
814	java -Xmx64G -jar pilon-1.22.jargenome my_assembly.fastafrags Aligned_PEreads_sorted.bam
815	jumps Aligned_MPreads_sorted.bamoutput ./my_assembly_polishedthreads 14
816	Note: Pilon seems to try to use more cpus than allowed with thethread option and requires more
817	memory to run on both paired ends and mate pairs. To counter this problem, we actually ran it on
818	28 cpus but passed less cpus (just enough to avoid memory issue) to thethread option.
819	
820	(8) Nanopolish polishing
821	Index the raw Nanopore reads (node=1:ncpus=1:mem=6gb; cput=02:30:00;walltime=02:30:00):
822	nanopolish index -d ./path_to_Fast5 -f List_summary.fofn -v ./Reads_basecalled_pass.fastq
823	
824	Index the assembly file (node=1:ncpus=6:mem=6gb; cput=00:10:00;walltime=00:10:00):
825	bwa index my_assembly.fasta
826	Align short-reads to assembly with <i>Bwa</i> (node=1:ncpus=28:mem=168gb;
827	cput=161:00:00;walltime=05:45:00):
828	bwa mem -x ont2d -t 28 my_assembly.fasta /path_to_raw_reads/Reads_basecalled_pass.fastq samtools
829	sort -o Reads.sorted.bam -@ 28
830	samtools index Reads.sorted.bam -@ 28
831	Run Nanopolish (node=1:ncpus=28:mem=168gb; cput=854:00:00;walltime=30:30:00):
832	python nanopolish_makerange.py my_assembly.fasta cat > Chunks.txt
833	more Chunks.txt parallelresults ./nanopol.res -P 7 nanopolish variantsconsensusfaster -o
834	polished.{1}.vcf -w {1} -r ./Reads_basecalled_pass.fastq -b ./Reads.sorted.bam -g ./my_assembly.fasta -t
835	4min-candidate-frequency 0.2

- Note: *Nanopolish* was unable to handle paths to directory others than the working directory,
 therefore we placed both raw indexed reads, the draft assembly and the sorted reads in the same
 directory.
- 839 Convert .vcf to .fasta (node=1:ncpus=1:mem=6gb; cput=00:03:00;walltime=00:30:00):
- 840 nanopolish vcf2fasta -g ./my_assembly.fasta ./polished.*.vcf > ./my_assembly_polished.fasta
- 841

842 (9) Quality assessment

- 843 *Quast* (node=1:ncpus=5:mem=30gb; cput=05:00:00;walltime=01:00:00;requires python/3)
- 844 quast.py -o /./ -R /path_to_reference_genome/Reference.fasta --threads 5 --min-alignment 400 --no-plot --
- 845 no-html --no-icarus --labels My_assembly --eukaryote /path_to_assembly/My_assembly.fasta
- 846 Note: walltime will depend on how divergent is the draft assembly from the reference assembly
- 847 Busco (node=1:ncpus=14:mem=84gb; cput=25:40:00; walltime=01:50:00; requires python/3,
- 848 augustus/3 and hmmer/3)
- 849 python run_BUSCO.py -i /path_to_assembly/My_assembly.fasta -o output_directory -I
- 850 ~/Programs/busco/diptera_odb9/ -m genome -c 14 -sp fly --blast_single_core
- 851

852 (10) Visualization with Dot

- 853 (node=1:ncpus=1:mem=6gb; cput=00:08:00; walltime=00:08:00)
- 854 nucmer -c 100 -t 3 -prefix=my_assembly /path_to_reference/Reference_genome.fasta
- 855 /path_to_assembly/My_assembly_100KB.fasta
- 856 python DotPrep.py --delta my_assembly.delta --out outputname --unique-length 10000 --overview 500000