



Continuous hydrothermal synthesis of doped barium zirconate powder for PCFC (Protonic Ceramic Fuel Cell) application

Mélanie François, François Maeght, Frédéric Demoisson, Gilles Caboche

► To cite this version:

Mélanie François, François Maeght, Frédéric Demoisson, Gilles Caboche. Continuous hydrothermal synthesis of doped barium zirconate powder for PCFC (Protonic Ceramic Fuel Cell) application. C’NANO (Le congrès commun SFNano C’Nano 2019), Dec 2019, DIJON, France. hal-03169162

HAL Id: hal-03169162

<https://hal.science/hal-03169162>

Submitted on 15 Mar 2021

HAL is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers.


L’archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d’enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.

Continuous hydrothermal synthesis of doped barium zirconate powder for PCFC application

Protonic Ceramic Fuel Cell

Mélanie François¹, François Maeght¹, Frédéric Demoisson¹, Gilles Caboche¹

¹ *Laboratoire Interdisciplinaire Carnot de Bourgogne, Université de Bourgogne Franche-Comté, Dijon, FRANCE*
melanie_francois@etu.u-bourgogne.fr





Abstract


BaZr_{1-x}M_xO_{3-δ} (M=Ce and/or Y) perovskite materials are good potential candidates for Protonic Ceramic Fuel Cell (PCFC) electrolyte due to their remarkable property of protonic conduction at intermediate temperature (400-600°C). Fabbri et al. have reported a protonic conductivity of 2.10⁻² S.cm⁻¹ at 600°C for BaCe_{0.7}Zr_{0.1}Y_{0.2}O_{3-δ} [1]. However, the synthesis of these materials requires high temperature (1500°C) by solid state reaction. The hydrothermal synthesis in supercritical water appears then as a way to synthesize perovskite materials at a temperature as low as 400°C. Furthermore, this process allows the formation of nanometric powder. Finally the continuous hydrothermal process offers many advantages such as: “soft-chemistry” route, low cost and sustainable elaboration.

Synthesis process


Continuous hydrothermal process developed at ICB laboratory



Supercritical water contribution




Batch process



Synthesized powders

BaZrO₃ (BZ)
σ_{bulk,600°C,wet H₂} = 5x10⁻³ S.cm⁻¹ [4]
σ_{total,600°C,wet H₂} = 2.1x10⁻⁶ S.cm⁻¹ [5]
T_{sintering} > 1700 °C
High stability



BaZr_{1-x}Y_xO_{3-δ} (BZYx)
↗ Protonic conductivity
BZY20
σ_{bulk,600°C,wet H₂} = 2.5x10⁻² S.cm⁻¹ [4]
σ_{total,600°C,wet H₂} = 6.3x10⁻³ S.cm⁻¹ [6]







BaZr_{1-x-y}Ce_xY_yO_{3-δ} (BZCYx)
T_{sintering} < 1500 °C
High stability
BZCY172
σ_{total,600°C,wet H₂} = 2.2x10⁻² S.cm⁻¹ [8]

BaCeO₃ (BC)
σ_{total,600°C,wet H₂} = 1.6x10⁻² S.cm⁻¹ [7]
T_{sintering} > 1700 °C
High stability

BaZr_{1-x}Ce_xO_{3-δ} (BZCx)
↗ Stability


Precursors:
Ba(NO₃)₂
ZrO(NO₃)₂·xH₂O
Ce(NO₃)₃·6H₂O
Y(NO₃)₃·6H₂O

Solvent:
H₂O, NaOH







Application as electrolyte for PCFC

Densification







- Necessary to add sintering aid (ZnO 1wt%)
- Sintering for 24h cause the evaporation of Ba and a segregation of phases
- Thermal treatment at 1000°C promotes densification and avoid segregation of phases
- Densification max = 92%
- Average particles size max = 2.25μm



Electrochemical Impedance Spectroscopy

Principle:
Applying a small quantity of sinusoidal voltage (or current) to perturb a system a measuring the response of the system (a oscillating current or voltage with a certain amplitude and shift depending on the frequency of the applied signal.

Set up:
Norec Probatat™
Metrohm Autolab™
Different atmospheres : dry H₂, wet H₂ (3%), dry O₂, wet O₂ (3%), dry N₂.
Temperature range : from 400 to 600°C



Conclusion

Synthesis

- BZY20 powder obtained by both continuous and batch process
- Less impurities with batch process but less production
- Synthesis of Ce-based compounds impossible by hydrothermal way due to the poor stability of BaCeO₃ against water containing atmosphere
→ Synthesis of BZY20 and BZCY172 by the continuous process trying to reproduce the conditions of the batch reactor

Sintering

- Using nanosized powder synthesized by hydrothermal process allows to reduce the sintering temperature from 1700°C to 1550°C
- Long sintering time causes the formation of undesirable phase
- Necessary to fire the powder at 1000°C in order to stabilize the crystal structure and promote a better densification without any secondary phase.

Electrochemical performances

BZY20 is a protonic conductor and became electronic conductor in dry O₂
Best total conductivity obtained in wet H₂ : 3.3x10⁻⁶ S.cm⁻¹ at 600°C on a non-dense sample