

# pH-sensitive polymethacrylate derivatives Eudragit E100 & L100 nanoparticles preparation in aqueous medium

Fabrice Ofridam, E. Gagnière, Noureddine Lebaz, Denis Mangin, Abdelhamid Elaïssari

#### ▶ To cite this version:

Fabrice Ofridam, E. Gagnière, Noureddine Lebaz, Denis Mangin, Abdelhamid Elaïssari. pH-sensitive polymethacrylate derivatives Eudragit E100 & L100 nanoparticles preparation in aqueous medium. 21st International Symposium on Industrial Crystallization, Aug 2021, Postdam, Germany. hal-03334747

HAL Id: hal-03334747

https://hal.science/hal-03334747

Submitted on 9 Nov 2023

**HAL** is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers. L'archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d'enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.



de génie des procédés, et de génie pharmaceutique.

# Precipitation and characterization of pH-sensitive polymers: effect of physicochemical parameters

Fabrice OFRIDAM<sup>1</sup>, Emilie GAGNIERE<sup>1</sup>, Noureddine LEBAZ<sup>1</sup>, Denis MANGIN<sup>1</sup> and Abdelhamid ELAISSARI<sup>2</sup> <sup>1</sup>Univ de Lyon, University Claude Bernard Lyon 1, CNRS, LAGEPP-UMR 5007, 43 Bd du 11 Novembre 1918, F-69622 Villeurbanne, France <sup>2</sup>Univ de Lyon, University Claude Bernard Lyon 1, CNRS, ISA-UMR 5280, 69622 Villeurbanne, France noureddine.lebaz@univ-lyon1.fr

### Introduction & Context


- Polymers in general and polymethacrylate derivates are largely used in numerous applications including drug encapsulation and in controlled oral drug delivery [1].
- pH-sensitive polymers are macromolecules that contain potential ionizable groups or hydrolyzable compounds and which react to pH variation by undergoing structural and property changes such as surface activity, chain structure, conformation, solubility and configuration [2].
- The use of pH-sensitive polymers to prepare pH-sensitive capsules or particles has not been widely reported probably due to the few potential applications of pH sensitive environment.
- Various pH-sensitive carriers have been reported but the literature is free from any deep characterization of the used polymers.

#### **Objectives**


- Investigation of the effect of different physicochemical parameters such as pH, salinity, polymer concentration, buffer concentration, and incubation time on the solubility and precipitation of two oppositely charged polymethyl methacrylate derivatives.
- Investigation of the effect of added secondary polymer or surfactant on the precipitation of both polymers
- Effect on size, size distribution, zeta potential and morphology of the particles.

#### **Materials**

Solubilization of Eudragit E100 in HCl medium as a function of polymer amount and time [3]





**Eudragit L100** Copolymer of methacrylic acid and methyl methacrylate in a ratio 1:1; MW=125000 g/mol





**Eudragit E100** Copolymer of dimethyl aminoethyl methacrylate, butyl methacrylate, and methyl methacrylate tri-copolymer with a ratio of 2:1:1; MW=47000 g/mol

#### Solubilization domains










- Grey bars on the 3D graphics refer to solubilized samples.
- ✓ L100 and E100 Eudragit polymers act respectively as polyacid and poly base
- In addition to the initial pH of the medium, the solubility conditions of the two investigated polymers are closely related to the polymer content and its incubation time.


- Solubilization of Eudragit L100 in NaOH medium as a function of polymer amount and time [3]
  - Solubilization studies in buffer solutions confirms that Eudragit L100 was soluble above pH = 6.50 and Eudragit E100 up to pH = 5.20
- By pH titration, it was found that Eudragit L100 contains around 4.8 nmol/mol of carboxylic groups and Eudragit E100 contains around 8.5 nmol/mol of ammonium groups.

# Polymers precipitation: Particle preparation and characterization

- Precipitated particles were micrometric in size with mean size between 30 and 50 µm, and large size distributions.
- TEM images show that all obtained dispersions are spherical polymer-based particles and highly polydisperse, which agrees with diameters deduced from diffraction light analysis.
  - Stabilization of submicronic Eudragit particles was made through (PECs) or complexation either as Polyelectrolytes complexes Polyelectrolyte-Surfactant complexes (PSCs)
- □Narrow size distribution around 200 nm was obtained when Eudragit L100 is precipitated in presence polyethylenimine (PEI) with particles zeta potential found to be +45mV. No aggregation and no sedimentation occurred.
- □Results suggest the formation of well defined spherical and monodisperse stabilized particles Eudragit polyethylenimine.




Volume-based hydrodynamic particle size distribution of particle formed in presence of polyethylenimine (PEI) as a function of w ratio (mass ratio polyelectrolyte/Eudragit polymer) [4].



SDS 4 and 8 mM (SDS/E100 charge ratio between 0,4 and 0,8)□Polymer precipitation as E100-

SDS particles

□Solubilization of complexes in micellar regimen ( > 8mM SDS)



☐ Charges Screening in micellar regimen between CTAB 4,5 and 6 mM (CTAB/L100 charge ratio between 0,3 and 0,4)

□Polymer precipitation as L100-CTAB particles

□Solubilization of complexes at high CTAB concentration ( > 8mM SDS)

# **Conclusion & Perspectives**

- Solubilization and precipitation domains of oppositely charged polyelectrolytes Eudragit L100 & E100 were clearly established
  - Eudragit L100 & E100 micrometric particles were prepared in buffer solutions
  - Stabilization of submicrometric Eudragit particles in aqueous solution was able through formation of PECs (200 nm spherical Eudragit L00polyethylenimine particles) or PSCs (stable oppositely charged E100/SDS & L100/CTAB complexes dispersions).
- Eudragit particles preparation by acidification or basification in confined systems (using the two microemulsions process) and based on results obtained in aqueous solutions was not successful.
  - It would be interesting to study the encapsulation efficiency of complexes prepared in aqueous solutions and their ability as potential nanocarriers.
- A better understanding of confined systems is needed at this point to continue the exploration of those systems for preparation of Eudragit L100 & E100 nanoparticles

## References

- [1] Ch. N. Patra, R. Priya, S. Swain, G. Kumar Jena, K. C. Panigrahi, and D. Ghose, Jun. 2017, doi: 10.1016/j.fjps.2017.02.001.
- [2] G. Kocak, C. Tuncer, and V. Bütün, "2017, doi: 10.1039/C6PY01872F.
- [3] C. Sester, F. Ofridam, N. Lebaz, E. Gagnière, D. Mangin, and A. Elaissari, Oct. 2019, doi: 10.1002/pat.4780.
- [4] F. Ofridam, N. Lebaz, É. Gagnière, D. Mangin, and A. Elaissari, Feb. 2020, doi: 10.1002/pat.4856.
- [5] F. Ofridam, N. Lebaz, É. Gagnière, D. Mangin, and A. Elaissari, 2021, doi: 10.1002/pat.5093