New sustainable synthetic routes to cyclic oxyterpenes using the Ecocatalyst toolbox - Supporting informations.

Camille Bihanic ¹⁺, Arthur Lasbleiz ¹⁺, Morgan Regnier ¹, Eddy Petit ², Pierre Le Blainvaux ³, and Claude Grison ^{1,3,*}


- Laboratory of Bio-inspirated Chemistry and Ecological Innovations (ChimEco), UMR 5021, CNRS – University of Montpellier
 D. b. 1602 – b. b. V. bi) 20700 C. b. b. F.
- Cap Delta, 1682 rue de la Valsière, 34790 Grabels, France 2 European Institute of Membrane (IEM), UMR 5635 – University of Montpellier
- 163 rue Auguste Broussonet, 34090 Montpellier, France
 BioInspir
 - Cap Delta, 1682 rue de la Valsière, 34790 Grabels, France
- * Correspondence: claude.grison@cnrs.fr
- **†** These authors contributed equally to this work.

Table des matières


I.	¹ H NMR spectra	2
	•	
		_
II.	Scale-up procedures	3

I. ¹H NMR Spectra


 β -pinene oxide in acetone-d₆




Myrtenol in acetone-d₆




7-Hydroxyterpineol in acetone-d₆




Perillyl alcohol in acetone-d₆



Perillaldehyde in acetone-d₆



Cuminaldehyde in acetone-d6



II. Scale up procedures

Scale-up for the synthesis of ß-pinene oxide 2.

ß-pinene 1 (38 mmol, 1 eq.), ecocatalyst (200 μ mol, 0.005 eq. of Mn) and NaHCO_{3 (aq)} (200 mmol, 5 eq.) were introduced in a flask containing distilled water (120 mL) and acetone (120 mL) at 30 °C for 10 minutes. H₂O_{2 (aq)} (40 % w/w in H₂O; 200 mmol, 5 eq.) was added dropwise for 2 h. After 2 h, the suspension was filtered and extracted three times with ethyl acetate. The organic layers were collected together and dried using anhydrous MgSO₄. The solvent was then evaporated. The crude was distilled under vacuum with a cooled trap.

Scale-up for the one pot synthesis of 7-hydroxyterpineol 4 from ß-pinene 1.

For the one-pot synthesis, β -pinene **1** (38 mmol, 1 eq.), ecocatalyst (200 µmol, 0.005 eq. of Mn) and NaHCO_{3 (s)} (200 mmol, 5 eq.) were placed in a mixture of distilled water (120 mL) and acetone (120 mL) at 30 °C for 10 minutes while stirring. H₂O_{2 (aq.)} (40 % w/w in H₂O; 200 mmol, 5 eq.) was added dropwise for 2 h using a syringe-pushing device. After 2 h, oxalic acid (304 mmol, 8 eq.) was added into the mixture. It was stirred for 1 more hour at 30 °C. It was then filtered and extracted three times with ethyl acetate. The organic layers were collected together and extracted with a saturated solution of NaHCO₃, then with brine before being dried using anhydrous MgSO₄. The solvent was evaporated.