

Using on-animal sensors to study the Ocean and its inhabitants

Journees « Drones et Capteurs » - Sept 2021







Centre d'études

biologiques de

Chizé

Pauline Goulet, on the behalf of Yan Roper-Coudert and Christophe Guinet



« Bio » « logging »?

- Refers to animal-attached remote sensing methods
- Biologging versus telemetry: Greek *tele* meaning far and *metros* meaning measurement
- Started with marine animals: most behaviour happens underwater → challenging to observe and follow!









Bio-logging / telemetry systems = the **only effective observational tool** for the study of many aspects of marine animal biology AND their environment

History

1940s

P. Scholander using a capillary depth gauge* on a freshlyharpooned bowhead whale records the first diving activity in the wild.

> * Based on the principle of capillarity proposed by Lord Kelvin in the 19th century, to measure the depth of the seabed from ships

SPERM WHALE (Physeter macrocephalus)

> SOUTHERN **ELEPHANT SEAL** (Mirounga leonina)

NORTHERN **BOTTLENOSE WHALE** (Hyperoodon ampullatus)

LEATHERBACKS (Dermochelys coriacea)

Discovery of the extraordinary diving ability of animals

(Aptenodytes forsteri)

1653m

1453m

2085m









564m

1300m

EMPEROR PENGUINS

History

G Kooyman developed the 1st time-depth recorder* to measure diving activity as a function of time.


1960s

* Using a kitchen timer in tandem with a pressure sensor. Cheap trick for big results! Since then the research grants in this domain have considerably increased.

First ecophysiological approach of diving activity.

WEDDELL SEAL (Leptonychotes weddellii)

> Maximum depth: 600 m Maximum duration: 43 min 20 s



SCRIPPSOCEANOGRAPHY




From Mechanical to Digital

Explosion & radiation: New sensor*, new data and new questions are booming all over the 👔

> * Among which: swim speed, dive angle, body posture, heart rate, internal and external temperature, micromovements, heading, etc.


Several aspects of the biology of an animal are studied simultaneously.

Wingbeat




Miniaturisation















Ropert-Coudert & Wilson 2005



LIMITING THE IMPACT

The 3% rule for airborne models

Respecting the streamlining of divers: the 1% cross-section rule







Case study: the elephant seal


- Large animal good to deploy devices
- Always comes back to the same place good to retrieve devices
- Regular and (almost) continuous diving
- Deep diver (regularly to 1000m)= good sampler
- Long distances during post-breeding and post-moult feeding trips



GPS tracks from 2018 DTAGs









Observing the biotic environment of animals: using a sonar



The sonar tag

- High frequency position (GPS) and movement sensors (accelero, magneto, depth)
 - Miniature active sonar:
 - 1.5MHz \rightarrow min object size 3 mm
 - up to 7m range,
 - up to 50Hz ping rate






To study

- biotic environment, prey field
- detailed information on prey





GOULET P, et al., (2019). A miniature biomimetic sonar and movement tag to study the biotic environment and predator-prey interactions in aquatic animals. Deep-Sea Research Part 1.



Sampling the biotic environment

Tournier et al., (2021) A novel animalborne miniature echosounder to observe the distribution and migration patterns of intermediate trophic levels in the Southern Ocean (Journal of Marine Systems)







Sampling the biotic environment

Diel vertical migration at Peninsula Valdes

Active vertical migration of living organisms (fish, squids etc)

Largest daily migration on Earth







6.



Measuring bioluminescence










Yoshino et al., J Exp Biol (2020) 223 (5): jeb212936.

Clip 3 (Taningia danae)



Developping new biologging techniques to observe and investigate intermediate trophic levels




High frequency position (GPS) and movement sensors (acc, mag, P)


High sensitivity-High frequency 50 hZ sampling Light sensor



To study brief **anti-predatory** emissions from bioluminescent organisms, e.g. myctophid fish, squids...


Goulet, P., et al. (2020). J. Exp. Biol. 223,






Under development: a microcamera-sonar tag











technology ltd

Naito : video camera (not sharp enough to identify small organisms (zooplankton taxonomic groups)

Merci de votre attention