

Non-targeted screening of extracts from polyester-phenolic can coatings: Identification of new aldehyde molecules from resole-based resins

Julien Terrasse, Marie Martin, Sarah Dubail, Patrice Dole, Hervé Casabianca

To cite this version:

Julien Terrasse, Marie Martin, Sarah Dubail, Patrice Dole, Hervé Casabianca. Non-targeted screening of extracts from polyester-phenolic can coatings: Identification of new aldehyde molecules from resolebased resins. Talanta, 2022, 243, pp.123351. 10.1016/j.talanta.2022.123351. hal-03648101

HAL Id: hal-03648101 <https://hal.science/hal-03648101v1>

Submitted on 22 Jul 2024

HAL is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers.

L'archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d'enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.

[Distributed under a Creative Commons Attribution - NonCommercial 4.0 International License](http://creativecommons.org/licenses/by-nc/4.0/)

Version of Record: <https://www.sciencedirect.com/science/article/pii/S0039914022001473> Manuscript_f7f30833b256222237ad2de19cffdc2b

1 **Non-targeted screening of extracts from polyester-phenolic can coatings:**

2 **identification of new aldehyde molecules from resole-based resins**

3 **Authors:**

4 Julien Terrasse^{a,b,*}; Marie Martin^b; Sarah Dubail^a; Patrice Dole^c; Hervé Casabianca^b

5 **Affiliations**

- 6 ^a The Valspar (France) Research Corporation SAS subsidiary of The Sherwin-Williams
- 7 company, 14 Rue Chanay, 71700 Tournus, France
- 8 ^b Université de Lyon, CNRS, Université Claude Bernard Lyon 1, Institut des Sciences
- 9 Analytiques, UMR 5280, 5 rue de la Doua, F-69100 Villeurbanne, France
- 10 CTCPA, Service sécurité et qualité des emballages, Pôle Alimentec Rue Henri de Boissieu,
- 11 01000 Bourg en Bresse, France

12 ***Corresponding author**

13 Julien Terrasse, julien.terrasse@sherwin.com; julien.terrasse@isa-lyon.fr

ABSTRACT

Phenolic and substituted phenol based resoles are commonly used in the formulation of can coatings. However, migration analyses of these coatings are very little described compared to other coating technologies. While epoxy and polyester have well known migrants with defined formation mechanisms, Non-Intentionally Added Substances (NIAS) specifically 20 related to the phenolic resin are hardly studied in the literature. The goal of the publication 21 is to further explore the influence of the phenolic resole, used in the formulation of can coatings, on extracted NIAS's nature. Six different model polyester-phenolic can coatings were formulated each with a specific phenol, cresol or tertbutylphenol-based resole. Can coating films were extracted for 24 hours at 40°C in acetonitrile before analysis. NIAS identification was done using gas chromatography separation coupled to high resolution mass spectrometry (HRMS) and nuclear magnetic resonance (NMR) spectroscopy analyses. 27 Cyclic polyester oligomers were found in all extracts, with oligomers found in a range of 10 μ g/dm² to 226 μ g/dm², without specific influence of the resole used in formulation. While very few or no peaks were detected from cresol- and phenol-based resoles, 48 peaks were specifically observed in coating extracts of formulas with tertbutylphenol-based resoles as well as in their respective resoles. The most intense peaks were identified as aldehyde compounds by HRMS and NMR analysis. These aldehydes were semi-quantified in similar proportions as polyester oligomers. The presence of such aldehydes has never been reported in the literature regarding NIAS in can coatings. Further study will then be needed to better understand the aldehyde formation mechanism and assess the toxicological profile of such chemicals.

KEYWORDS

Food contact material, Can coating, Resole, NIAS, Non-targeted analysis, High resolution mass spectrometry

Introduction

As with any Food Contact Material (FCM), internal can coatings are strictly regulated to ensure that no substances may be transferred into the food in quantities which could endanger human health or impact organoleptic properties of the food [1]. The transfer of substances does not only concern unreacted substances such as residual monomers and additives, but Non-Intentionally Added Substances (NIAS) as well. NIAS are defined as all migrating substances which are not introduced in the FCM for technical reasons. They can be for example raw material impurities, side reactions and decomposition products [2]. There are a large variety of plausible NIAS due to resins syntheses, coating formulation and curing process. NIAS analysis is a significant task and essential to ensure the safety of can coatings. Many studies have been focused on NIAS, monitoring them in several main coating technologies: polyester oligomers [3–8], Bisphenol A, its analogues and derivatives in epoxy resins and coatings [9–12] and in acrylic based adhesives [13,14]. There are few studies specifically aimed at the influence of phenolic resins on the nature and quantity of the potential NIAS [15,16]. Moreover, to the best of the authors' knowledge, studies on NIAS extractions from coatings using substituted phenol based resole in their formulation were never published. Only one study has been reported on the compositions of the substituted resoles themselves [17].

Phenolic resins based on phenol and alkylated phenol resoles are frequently used as cross-linkers in internal coatings of metal cans for food contact application [18,19]. Resoles are the most used phenolic resin in the formulation of can coatings. These are produced through the

polycondensation of phenol or substituted phenol (cresol, 4-tert-butylphenol) with formaldehyde excess in alkaline conditions (**Figure 1**). The reaction leads to the formation of hydroxymethyl group substitutions in ortho and para positions of the phenolic ring, usually called methylol [15,20]. A self-condensation then takes place through the reaction of two methylol groups and produces oligomers consisting of a phenolic ring linked by a methoxy bridge. This latter is further transformed into a methylene bridge with the loss of formaldehyde. The condensation finally leads to the final network of the resole constituted of phenolic rings linked by methylene bridges [21,22]. In addition, resoles used for can coating formulations are usually solubilized in alcoholic solvents, such as butanol, which can lead to the etherification of residual methylol [15,16]. Several phenolic resins can be used in a coating formulation being added to polyester, epoxy or acrylic resins in order to give specific performances to the cured coating, thereby adding potential new NIAS due to the multiplicity of raw materials.

The present study focuses on the detection, identification and semi-quantification of NIAS extracted from polyester-phenolic can coatings. Model formulations were prepared with high concentrations of resole of different natures: based on phenol, cresol or 4-tertbuyl phenol (TbuP). Coatings with one resole each were applied and cured. Gas chromatography (GC) coupled to mass spectrometry (MS) and high resolution mass spectrometry (HRMS) analyses were conducted after extraction into acetonitrile. Liquid chromatography coupled 80 to mass spectrometry (LC-MS) is one of the most used analytical techniques in literature for FCM extraction and migration analyses. But the chemical structure of phenolic molecules makes them not well adapted for LC-MS analysis. The expected phenolic molecules (**Figure 1**) are difficult to charge with the usual positive ionisation, leading to a low sensitivity, while the overall signal is usually lower with a negative ionisation. These problems linked to the

85 ionisation could be one of the reasons for the scarce literature on phenolic NIAS. On the other side, GC-MS has already been used to analyse resoles [15–17], where the main oligomers were found between 100 and 600 Da, but never to identify extracted NIAS due to substituted phenol based resole in can coatings. Theoretical databases and HRMS were used for the identification of NIAS and further mono and bi-dimensional nuclear magnetic resonance (NMR) spectroscopy analyses were done to overcome identification uncertainty.

1. Materials and methods

1.1. Reagents

Acetonitrile (LC-MS Chromasolve grade, >99.9%) for extractions and calibration solutions was purchased from Honeywell (Levallois Perret, France). Acetonitrile is one of the best extractants for polyester coatings and does not lead to hydrolysis of polyester oligomers [23].

Deuterated acetonitrile-d3 (99,6% D) from CEA (France) was used as solvent in NMR analysis. Analytical standards 4-tert-butyl-2,6-diformylphenol (CAS 84501-28-0, >96%) was purchased from Sigma-Aldrich (Saint Louis, MO, USA), Diethyl terephthalate (CAS 636-09-9, >99,0%) from TCI Chemical (Tokyo, Japan) and Ethylene Terephthalate Cyclic Dimer (CAS 24388-68-9, 98%) from Toronto Research Chemicals (Toronto, Canada). All chemicals used for coating preparation were supplied by Valspar and formulations are proprietary to Valspar. **1.2. Coating's formulation and curing**

Six different polyester-phenolic coatings were prepared based on a model formula, using in each of them one specific phenolic resin:

− Phenol based (P-1, P-2 & P-3)

− Cresol based (C-1)

− Tertbutyl phenol (TbuP) based (TbuP-1 & TbuP-2)

Formulas were developed to feature 20% of resole in its non-volatile content. All coatings were prepared following the same protocol. To a polyester resin, solvents (acetate and diacetate mix), slip agent and defoamer were added under stirring. A caprolactam blocked isophorone diisocyanate solution and a resole were then added. Wax and catalyst were finally added to complete the formulation. In addition, a polyester coating without phenolic resin was prepared.

The polyester resin is based on isophthalic (IPA) and terephthalic acid (TPA), ethylene glycol (EG), neopentyl glycol (NPG), hexan-1,6-diol (HD) and trimethylolpropane. IPA and TPA are 117 referred as phthalic acid as both isomers cannot be differentiated in mass spectrometry. 118 Electrolytic tin plates were coated using a wire-wound bar to obtain a 10g/m² cured film. Coated plates were cured for 14min at 205°C in a calibrated electric oven to mimic real temperature profile of a 10min at 200°C industrial cure and take into account the loss of temperature due to the door opening and its restabilisation.

1.3. Sample extraction and preparation

Two extractions were done for each formulation. For each extraction experiment, a 6 cm x 124 25 cm band (1,5dm² area) was cut from a coated panel. The band was then cut into smaller 3 cm x 5 cm pieces. Pieces were folded in an accordion style, to ensure that the entire surface was available to the extraction solvent and placed in a glass bottle. 50 mL of acetonitrile was 127 added, and the bottle was tightly shut and left for 24 hours at 40°C. Extractions at room temperature, 40°C and 60°C for 24 hours were carried out but no difference was observed. 40°C extraction was chosen as final procedure.

20 mL of the extract were collected and concentrated to 2 mL by evaporation before GC-MS and GC-Orbitrap analysis. Diethyl terephthalate (DET) was spiked in the sample as an internal standard to ensure no matrix effect or injection failure may have occurred during the analysis.

1.4. Instrumentation

1.4.1. Screening and semi-quantification by GC-MS

Initial screening used a 6890N GC gas chromatography equipped with a 7683 autosampler hyphenated to a 5975 inert XL MSD mass spectrometer from Agilent Technologies (Santa Clara, CA, USA) with electronic impact (EI) ionization (70eV). Extracts were injected without derivatisation to avoid unpredicted chemical reactions and ease the identification process. 140 1 μ L of sample was injected in splitless mode with an injector temperature set at 280 \degree C. Helium was used as carrier flow with a 1mL/min flow. An HP-5MS capillary column (30 m x 0.25 mm x 0.25 μm, Agilent Technologies) was used for the separation. The oven program started at 80°C for 2 min, increased to 270°C at 10°C/min, held for 20 min before a last ramp 144 to 320°C at 5°C/min and then held for 15 min. The scanning mass range was from 50 to 750 Da.

Data treatment was done on MSD Chemstation software. Integration parameters set at a 147 minimum peak area of 10^5 and a threshold of 15 while NIST 14 and Wiley 275 databases were used for tentative identification.

Semi-quantification was realised by an internal standard quantification with diethyl terephthalate as internal standard. As analytical standards were not available for most of the identified NIAS, the closest available molecules were used. 4-tert-butyl-2,6-diformylphenol calibration curve was used for phenol-based molecules and ethylene terephthalate cyclic

dimer for polyester oligomers. Response factors were considered as equivalent to those of their respective standard. Calibration curves were established from 1 to 50µg/mL with R^2 >0,99. The calibration curves lead to a LOQ of 10 μ g/dm² for ethylene terephthalate cyclic 156 dimer and 6µg/dm² for 4-tert-butyl-2,6-diformylphenol.

1.4.2. Screening and identification by GC-Orbitrap

A Q-Exactive Orbitrap mass spectrometer with EI ionisation, hyphenated to a Trace 1310 GC and TriPlus RSH autosampler from Thermo Scientific (Bremen, Germany), was used for GC-160 HRMS screening. PTV injector was set at 280°C and 1µL of sample was injected in splitless mode. Helium was used as carrier gas with a 1.2mL/min flow. Separation was done on a TG-5SILMS capillary column (30 m x 0.25 mm x 0.25 μm, Thermo Scientific). The oven temperature started at 80°C with an initial hold of 4 min before a ramp to 320°C at 10°C/min and held for 15 min. Mass spectrometer was set to a resolution of 60000 FWHM (m/z 200) on full scan with a range scan from 50 to 750 Da. The automatic gain control (AGC) was 166 targeted at 10^6 with a maximum injection time of 200ms. Two different electron energies were used: 70eV and 10eV. Data were processed with Xcalibur and TraceFinder 4.1 (Thermo 168 Scientific). Screening for compounds used TraceFinder with a threshold TIC of 10⁷, S/N of 100 and ion overlap at 97%.

A fragmentation at 70eV was used for all samples, allowing spectra comparison with NIST 2.2 database. A second analysis using 10eV fragmentation energy was carried out in order to avoid avoiding fragmentation and approaching the molecular mass of the compounds. The combination of both HRMS spectra is used for the identification process of unknown NIAS: the monoisotopic mass and molecular formulas of fragments were proposed by the software within a 5 ppm mass deviation between theoretical and experimental masses. NIAS could be

identified using combinations of molecular formulas, associated rings and double bonds

(RDB) equivalent, fragmentation patterns, databases and literature.

178 **1.4.3. Identification by ¹H and ¹³C-NMR**

For NMR analysis, extract samples and phenolic resins were taken up in deuterated acetonitrile after evaporation of the extraction solvent. A Bruker Avance III HD 400 from Bruker at 30°C with a 5mm PABBO BB/19F-1H/D Z-GRD probe was used. Samples were 182 characterised by ¹H, ¹³C and DEPT135 mono-dimensional spectra as well as HSQC and HMBC $1H-13C$ bi-dimensional experiments to observe proton-carbon correlations. Spectra were calibrated to the solvent signal.

1.5. Theoretical databases

To help the identification of NIAS, a predictive database was created, listing all possible polyester oligomers with a molecular weigh less than 1000 Da. The limit of 1000 Da was chosen as only molecules with a molecular weight inferior to 1000 Da are considered to be possibly assimilated by the organism through the gastrointestinal tract [2,24]. Knowing the polyester resin monomeric composition, all the possible linear and cyclic oligomer combinations can be predicted from the successive esterifications. A set of iterative procedures were developed in Microsoft Excel Visual Basic for Applications (VBA) to automatize the process for any monomer composition and to calculate molecular mass for future analysis. More than 250 possible oligomers were obtained with the monomeric composition of the resin used in the formulas. A similar method was used for phenolic resin databases which proposed around 400 possible oligomers based on phenol and 150 oligomers for each cresol and TbuP.

2. Results and discussion

- **2.1. NIAS associated to polyester resin**
-

2.1.1. Identification by GC-HRMS

available databases were compared to experimental results. As a result, the NIAS was

222 identified as a cyclic oligomer based on two EG and at least one IPA. This protocol allowed the identification of 13 different cyclic oligomers of polyester based on EG, NPG and HD with different isomers due to IPA and TPA combinations (Table **1**).

Polyester oligomers were only identified as cyclic oligomers. This prevalence can be explained by the resin synthesis with high molecular weight. The polyester resin used is specified with an average molecular weight (Mn) higher than 5000 Da, short linear chains are very small proportions of the initial resin. Furthermore, linear oligomers are expected to react during the curing of the coating with the diisocyanate cross-linker due to their pendant functions. On the contrary, once cyclic oligomers are formed during the resin synthesis, they would not be able to further react during the overall curing process. They would not be chemically linked to the coating network and therefore could be extracted [6,8]. This tendency is accentuated by the fact that extraction is done in a solvent with which no hydrolysis can occur [23].

2.1.2. Polyester oligomers semi-quantification

Polyester oligomers were quantified using the cyclic TPA-EG-TPA-EG calibration. The 237 quantities of oligomers were compared to observe the influence of the resole chemistry on the quantity of extracted polyester oligomers (**Table 2**).

Formulas with phenol based resole have a total oligomer content ranging from 363 to 467

240 µg/dm². Results for the three other coatings have comparable levels of oligomers, 447 and

241 $506 \mu g/dm^2$ in the two TbuP cases and 397 $\mu g/dm^2$ for the cresol-based formula.

242 Quantification results are in line with previous studies on polyester coatings where individual

cyclic oligomers or total oligomer contents were quantified in acetonitrile and ethanol

extractions [3,4,30]. The choice of resole used in the formulation has no specific impact on

the quantities of extracted oligomers of polyester. The noted variations from one formula to another are judged more likely to be due to the variation of resin quantity from one coating 247 to another during its formulation rather than an effect of the resole. Moreover, the non-248 influence of the resole toward cyclic oligomers may be related to the absence of reactive site 249 on the cyclic oligomers or any hydrolysis possibility during the coating formulation and cure.

2.2. NIAS associated to phenolic resins

2.2.1. Identification by GC-HRMS

Analysis of extracts from formulations with alkylated phenol-based resole had chromatograms with intense peaks which were not detected in phenol-based formula. This is particularly observed in TbuP-1 and Tbu-2 extracts, where respectively 42 and 26 additional peaks were detected. With C-1-based coating, only 4 peaks were specifically observed, with lower intensities. The same protocol as for polyester oligomers had been applied on the experimental spectra to identify those compounds (**Figure 2**). Some of these new peaks could be identified as usual phenolic oligomers based on a tertbutyl-phenol base with methylol and butylated methylol substitutions. Yet, the most intense peaks could not be identified with this method. A conflict appeared between proposed molecular formula, expected phenolic oligomers and the NIST identification. Different alkylated phenols were proposed by the NIST database with low match results and accurate masses did not match with the molecular formula of predicted oligomers. Taking one of the most intense unidentified peaks as an example, proposed molecular formula and fragmentation patterns 265 were indicating an expected tertbutyl substitution noticeable through the loss of CH₃ (m/z = 191.0702) and C3H7 (m/z = 163.0389) from the monoisotopic mass (m/z=206.0937) (**Figure 3**). Its proposed formula was $C_{12}H_{14}O_3$ and by considering the presence of tertbutyl substitution on the phenolic ring, the only possible structure was the addition of two

aldehyde functions on the aromatic ring. This particular compound identification was

suspected to be 4-tert-butyl-2,6-diformylphenol. The presence of that aldehyde substitution

was suspected for several unidentified NIAS.

The presence of multiple suspected aldehyde molecules was not expected as no mention of

273 this chemistry appears in the literature relative to coating extraction, migration or even in

274 other FCMs. Those compounds are linked to the use of TbuP resole since they were only

observed in samples from coatings TbuP-1 and TbuP-2. Biederman and Grob highlighted the

presence of compounds which did not fit the usual scheme of phenolic oligomers in the TbuP

resole itself, but no identification was done [17].

Looking at C-1 extraction, specific peaks are fewer and less intense than those observed in

TbuP analysis, but aldehyde molecules were suspected as well.

2.2.2. Liquid coatings and TbuP resoles analyses

The few studies mentioning aldehyde presence were done on the resole [33–36]. Both the

liquid coatings and the TbuP resoles were directly extracted in acetonitrile by manual

shaking followed by a 10min centrifugation at 1465 RPM. Supernatant was directly injected

in GC-MS and chromatograms were compared with those of cured coating extractions.

All peaks specifically observed in the TbuP cured coating extracts were present in both liquid coating and initial resole. Therefore, these compounds were suspected as side products of TbuP resole synthesis.

2.2.3. Validation of one specific NIAS identification

A standard of 4-tert-butyl-2,6-diformylphenol was purchased and analysed with the same analytical method as for coating extracts. The standard showed the same retention time and fragmentation in GC-MS analysis as its suspected peak (**Figure 4**). The presence of the multiple aldehyde molecules is then a plausible hypothesis and this standard was used for semi-quantification of NIAS from the phenolic resins.

2.2.4. Validation of the identification of aldehydes by NMR

295 Cured coating extracts were insufficiently concentrated for 13 C NMR. The signal intensity was 296 sufficient to observe additional peaks in TbuP-1 by H NMR. Specific peaks were observed 297 when compared to P-2 spectrum. Those protons were found with chemical shift (δ) of 10.6, multiple peaks from 8.5 to 7.6 ppm, 5.7 and 2 ppm. The signal at 10.6 ppm is specific to the presence of aldehyde or carboxylic acid functions. Protons at 8.5 and 7.6 ppm are in the range of aromatic protons and could be related to protons with specific chemical shifts due to the aldehyde substitution. Concerning the proton at 2 ppm, it is likely related to the hydrogen of the tertbutyl group.

In order to improve the signal intensity, extractions of liquid coatings TbuP-1 and P-2 were 304 analysed. This way not only ¹H, ¹³C and 135DEPT but ¹H-¹³C bi-dimensional experiments HSQC and HMBC (**Figure 5**) could be done to identify the presence of aldehyde functionality and its position in the molecule structure. HSQC shows correlations between carbons and hydrogens which are directly bonded while correlations between carbons and protons separated by two or three chemical bonds are obtained using HMBC.

309 The protons specifically detected by ¹H NMR were correlated to their corresponding ¹³C 310 NMR signals (**Table 3**). A peak at 199 ppm in ¹³C NMR with a corresponding positive peak in 135DEPT is correlated with the 10.6 ppm proton. This chemical shift and DEPT value are specific of primary and tertiary carbons from carbonyl functions. Considering the previous ¹H

NMR conclusions, the only possibility to observe such a carbon-proton correlation is the presence of an aldehyde function.

315 Moreover, using correlation in HMBC, the 1 H signal of the aldehyde is correlated with 316 aromatic carbons, with δ^{13} C varying from 121 ppm to 158 ppm. These carbons are clearly 317 identified as aromatic with their HSQC correlations with hydrogens with δ ¹H of 7.6 ppm to 8.5 ppm. The aldehyde function is then substituted to the aromatic ring, which is in line with the suspected structure given to the NIAS.

Concerning the proton at 5.7 ppm, it was correlated in HSQC with a carbon at 70 ppm with a negative DEPT value. In parallel, the proton was correlated to the aromatic carbons by HMBC. This signal could be attributed to the methylol substitution as a secondary carbon was expected from DEPT spectrum and both chemical shifts are in line with theoretical ones. In conclusion of the NMR analysis, using both chemical shifts and correlations, similar structures to 4-tert-butyl-2,6-diformylphenol matched the experimental specific signals in

TbuP-1 spectra. The hypothesis stated with the GC-HRMS analysis was then validated: newly identified aldehydes are present in coating extractions. The origin of those compounds was attributed to the resole itself as a potential side-product of its synthesis.

2.2.5. Influence of resole nature on extracted NIAS from can coatings

Following the validation of aldehyde presence, 28 NIAS from TbuP-based coatings could be identified and molecular formula proposed. A semi-quantification of all peaks due to phenolic resins was done using 4-tert-butyl-2,6-diformylphenol as standard (**Table 4** & **Table 5**).

Butyl substitution was identified as well and was related to the presence of butanol or tertbutanol in resole which can react with pendant methylol groups. Concerning methyl substitution, the methyl presence was not necessarily related to an etherification of a pendant methylol. From proposed molecular formula, more particularly the number of oxygens, methyl substitution has been suspected as a direct substitution on the aromatic ring.

No reference to aldehyde in resoles could be found in the literature regarding NIAS analyses in can coatings. As phenolic resins are used in other polymeric applications, a few studies have been found mentioning aldehydes presence in resole. TbuP+F had been identified in a TbuP based resin used in ink pen [33]. Aldehydes have been seen in phenol based resole [34–36]. Bouajila et al. proposed a mechanism using a cleavage of the methoxy bridge into an aldehyde and a methyl-substituted phenol. Such mechanism could explain the presence of the methyl substitution on the aromatic ring. Regardless, the oxidation of methylol into aldehyde could be the result of different mechanisms such as an oxydo-reduction reaction between phenolate and formaldehyde (**Figure 6**).

While tested phenol and cresol-based resoles were responsible for respectively none and very few extracted NIAS, TbuP-based resoles were sources of several phenolic compounds. Moreover, the presence of those compounds was not negligible, as the NIAS due to the TbuP resoles were more abundant in the film extracts than polyester oligomers (**Figure 7**). The 353 most abundant phenolic NIAS was semi-quantified at 137 and 249 µg/dm² in TbuP-1 and TbuP-2 extracts. In comparison, the most abundant polyester oligomer was quantified at 226 355 and 178 μ g/dm² in the corresponding extracts. Moreover, while cyclic oligomer EG-PA-EG-PA 356 is the only oligomers found in quantities higher than $50\mu g/dm^2$, 4 phenolic NIAS were found in higher concentrations in TbuP-1 and 3 in TbuP-2, notably with a concentration of 249

358 μ g/dm² for TbuP + F + MOH, which is the most abundant NIAS found in all the analyses. The choice of the resole for the formulation of a can coating was then a major parameter to limit the extracted quantity of NIAS from can coatings.

3. Conclusion

To investigate the influence of phenolic resins on NIAS extractions of can coatings, six different model coatings were formulated, each using one specific resole. Different resoles based on phenol, cresol and TbuP were used.

Two groups of NIAS were identified in film extracts thanks to predictive databases of oligomers and HRMS treatment: cyclic polyester oligomers, already reported in literature, and NIAS specifically found in alkylated phenol-based resoles. While the choice of resole had no impact on the quantity of cyclic oligomers of polyester, the use of TbuP-based resoles led to the detection of an important number of specific NIAS among which the most abundant were identified as aldehydes. 4-tertbutyl-2,6-diformyl phenol was directly identified by GC-MS and the presence of a formyl group substituted on the phenolic ring had been demonstrated by bi-dimensional NMR. Moreover, the aldehyde components were not only found in film extracts but also in liquid coating and resole extracts, thus the NIAS were directly present in the native resole as side-products of their production process and were not produced within the formulation or the cure of the coating.

These new aldehyde molecules were never identified in FCM literature. While absent or only detected at marginal levels in phenol and cresol-based phenolic coatings, these aldehyde substituted phenols were semi-quantified in larger amounts than the polyester oligomers in TbuP-based phenolic coatings and should be further studied in future analysis. The absence of phenolic NIAS in phenol-based resole could be explained by the additional active site on

the phenolic ring. Contrary to alkylated phenols, aldehydes produced during the synthesis of the resole are more easily included in the overall polymeric network during the condensation thanks to the two remaining active sites, preventing their extraction. In the same way, the difference between cresol and TbuP may be due to the more sterically hindered tertbutyl group, decreasing the condensation rate and favouring side reactions of the smaller oligomers **(Figure 6)** leading to the formation of aldehydes. Another hypothesis could be the differences of process for the resoles synthesis. Because of the different end applications and reaction rates of monomers, specific processes for TbuP resole production could enhance the side production of aldehydes.

Finally, considering the risk assessment of these new NIAS, further studies are needed as current testing was performed on model formula designed to specifically study the presence of phenolic related NIAS. Migration tests on commercial can coatings should verify the presence and the quantities of these compounds in real situations of food contact with TbuP phenolic coatings, since food simulants and ultimately real foodstuff can have different extracting capacities than acetonitrile [23] and since commercial formulas usually use a mix of different phenolic resins at different ratios. Further evaluations of the identified aldehyde substances must be realised, especially regarding their more accurate quantification and toxicology in order to determine safe levels of exposure in case some would ultimately migrate into food. Organoleptic profile of the substances could as well be of interest, some aldehydes being known to be flavouring or fragrant. These findings, integrated in the selection of raw materials according to a Safety-by-Design approach may be very useful to contribute to the design of future low migration coatings.

Authorship contribution statement

- **Julien Terrasse:** Conceptualization, Methodology, Validation, Formal analysis, Investigation,
- Writing original draft, Writing review & editing, Visualisation. **Marie Martin:** Formal
- analysis, Validation, Writing review & editing. **Sarah Dubail:** Conceptualization,
- Supervision, Project administration, Funding acquisition, Writing review & editing. **Hervé**
- **Casabianca:** Conceptualization, Supervision, Project administration, Funding acquisition,
- Writing review & editing. **Patrice Dole:** Conceptualization, Supervision, Project
- administration, Funding acquisition, Writing review & editing.

Declaration of competing interest

- The authors declare that they have no known competing financial interests or personal
- relationships that could have appeared to influence the work reported in this paper.

Acknowledgement

- The authors would like to thanks Mr Peter Oldring and Pr Bernard Sillion for their advices
- and assistance throughout this study and the review of this paper.
- This work was conducted in partial fulfilment of the PhD requirements for Julien Terrasse
- who has received a grant from the ANRT (Association Nationale de la Recherche et de la
- Technologie, Paris, France). The research was supported by a contract between The Valspar
- (France) Research Corporation SAS, ISA (Institut des Sciences Analytiques, Villeurbanne,
- France) and CTCPA (Centre technique de la Conserve et des Produits Agricoles, Bourg en
- Bresse, France).

References

[1] European Parliament, Regulation (EC) No 1935/2004 on materials and articles intended to come into contact with food and repealing Directives 80/590/EEC and 89/109/EEC, 2004. http://data.europa.eu/eli/reg/2004/1935/oj.

427 [2] European commission, Commission Regulation (EU) No 10/2011 of 14 January 2011 on plastic materials and articles intended to come into contact with food, 2011.

http://data.europa.eu/eli/reg/2011/10/2020-09-23.

- [3] M. Driffield, M. Garcia-Lopez, J. Christy, A.S. Lloyd, J.A. Tarbin, P. Hough, E.L. Bradley, P.K.T. Oldring, The determination of monomers and oligomers from polyester-based can coatings into foodstuffs over extended storage periods, Food Addit. Contam. Part A. 35 (2018) 1200–1213. https://doi.org/10.1080/19440049.2018.1440643.
- [4] M. Eckardt, L. Hetzel, F. Brenz, T.J. Simat, Release and migration of cyclic polyester oligomers from bisphenol A non-intent polyester–phenol-coatings into food simulants and infant food – a comprehensive study, Food Addit. Contam. Part A. 37 (2019) 681– 703. https://doi.org/10.1080/19440049.2019.1616831.
- [5] M. Hoppe, P. de Voogt, R. Franz, Identification and quantification of oligomers as potential migrants in plastics food contact materials with a focus in polycondensates – A review, Trends Food Sci. Technol. 50 (2016) 118–130. https://doi.org/10.1016/j.tifs.2016.01.018.
- [6] E. Omer, R. Cariou, G. Remaud, Y. Guitton, H. Germon, P. Hill, G. Dervilly-Pinel, B. Le Bizec, Elucidation of non-intentionally added substances migrating from polyester-polyurethane lacquers using automated LC-HRMS data processing, Anal. Bioanal. Chem. 410 (2018) 5391–5403. https://doi.org/10.1007/s00216-018-0968-z.
- [7] R. Paseiro-Cerrato, S. MacMahon, C.D. Ridge, G.O. Noonan, T.H. Begley, Identification of unknown compounds from polyester cans coatings that may potentially migrate into food or food simulants, J. Chromatogr. A. 1444 (2016) 106–113.
- https://doi.org/10.1016/j.chroma.2016.03.038.
- [8] A. Schaefer, V.A. Ohm, T.J. Simat, Migration from can coatings: Part 2. Identification and quantification of migrating cyclic oligoesters below 1000 Da, Food Addit. Contam. 21 (2004) 377–389. https://doi.org/10.1080/02652030310001637939.
- [9] P. Cao, H. Zhong, K. Qiu, D. Li, G. Wu, H. Sui, Y. Song, Exposure to bisphenol A and its substitutes, bisphenol F and bisphenol S from canned foods and beverages on Chinese market, Food Control. 120 (2021) 107502.
- https://doi.org/10.1016/j.foodcont.2020.107502.
- [10] A. Lestido-Cardama, R. Sendón, J. Bustos, M.I. Santillana, P. Paseiro Losada, A. Rodríguez Bernaldo de Quirós, Multi-analyte method for the quantification of bisphenol related compounds in canned food samples and exposure assessment of the Spanish adult population, Food Packag. Shelf Life. 28 (2021) 100671.
- https://doi.org/10.1016/j.fpsl.2021.100671.
- [11] A. Schaefer, T.J. Simat, Migration from can coatings: Part 3. Synthesis, identification and quantification of migrating epoxy-based substances below 1000 Da, Food Addit.
- Contam. 21 (2004) 390–405. https://doi.org/10.1080/02652030310001657388.
- [12] J. Wagner, L. Castle, P.K.T. Oldring, T. Moschakis, B.L. Wedzicha, Factors affecting migration kinetics from a generic epoxy-phenolic food can coating system, Food Res. Int. 106 (2018) 183–192. https://doi.org/10.1016/j.foodres.2017.12.059.
- [13] E. Canellas, P. Vera, C. Domeño, P. Alfaro, C. Nerín, Atmospheric pressure gas chromatography coupled to quadrupole-time of flight mass spectrometry as a powerful tool for identification of non intentionally added substances in acrylic adhesives used in food packaging materials, J. Chromatogr. A. 1235 (2012) 141–148.
- https://doi.org/10.1016/j.chroma.2012.02.039.
- 473 [14] E. Canellas, C. Nerín, R. Moore, P. Silcock, New UPLC coupled to mass spectrometry approaches for screening of non-volatile compounds as potential migrants from
- adhesives used in food packaging materials, Anal. Chim. Acta. 666 (2010) 62–69.
- https://doi.org/10.1016/j.aca.2010.03.032.
- [15] M. Biedermann, K. Grob, Phenolic resins for can coatings: I. Phenol-based resole analysed by GC–MS, GC×GC, NPLC–GC and SEC, LWT - Food Sci. Technol. 39 (2006) 633–646. https://doi.org/10.1016/j.lwt.2005.04.008.
- [16] M. Eckardt, R. Benisch, T.J. Simat, Characterisation, release and migration of phenolic compounds from resoles used in polyester-phenol coatings intended for food contact materials, Food Addit. Contam. Part A. 37 (2020) 1791–1810.
- https://doi.org/10.1080/19440049.2020.1782480.
- [17] M. Biedermann, K. Grob, Phenolic resins for can coatings: II. Resoles based on cresol/phenol mixtures or tert. butyl phenol, LWT - Food Sci. Technol. 39 (2006) 647– 659. https://doi.org/10.1016/j.lwt.2005.04.007.
- [18] B. Geueke, Food Packaging Forum Dossier: Can coatings, (2016). https://doi.org/10.5281/zenodo.200633.
- [19] P.K.T. Oldring, U. Nehring, Metal packaging for foodstuffs: report prepared under the responsibility of the ILSI Europe Packaging Material Task Force, ILSI Europe, Brussels, 2007.
- [20] W.D. Detlefsen, Chapter 20 Phenolic resins: some chemistry, technology, and history, in: D.A. Dillard, A.V. Pocius, M. Chaudhury (Eds.), Adhes. Sci. Eng., Elsevier Science B.V., Amsterdam, 2002: pp. 869–945. https://doi.org/10.1016/B978-044451140-9/50020-2.
- [21] J. Bouajila, G. Raffin, H. Waton, C. Sanglar, J.O. Païsse, M.F. Grenier-Loustalot, Phenolic Resins – Characterizations and Kinetic Studies of Different Resols Prepared with Different Catalysts and Formaldehyde/Phenol Ratios (I), Polym. Polym. Compos. 10 (2002) 341–359. https://doi.org/10.1177/096739110201000502.
- [22] J. Lang, M. Cornick, Resole Production, in: L. Pilato (Ed.), Phenolic Resins Century Prog., Springer, Berlin, Heidelberg, 2010: pp. 139–146. https://doi.org/10.1007/978-3-642- 04714-5_6.
- [23] R. Paseiro-Cerrato, G.O. Noonan, T.H. Begley, Evaluation of Long-Term Migration Testing from Can Coatings into Food Simulants: Polyester Coatings, J. Agric. Food Chem. 64 (2016) 2377–2385. https://doi.org/10.1021/acs.jafc.5b05880.
- [24] European Council of the Paint, Printing Ink, and Artist's Colours Industry (CEPE), TSC33 NIAS Guidelines For Coated Rigid Metal Packaging Intended For Direct Food Contact-version 1.7.5, 2019. https://www.cepe.org/search/TSC 33/ (accessed April 12, 2021).
- [25] C. Nerin, P. Alfaro, M. Aznar, C. Domeño, The challenge of identifying non-intentionally added substances from food packaging materials: A review, Anal. Chim. Acta. 775 (2013) 14–24. https://doi.org/10.1016/j.aca.2013.02.028.
- [26] M.J. Martínez-Bueno, M.J. Gómez Ramos, A. Bauer, A.R. Fernández-Alba, An overview of non-targeted screening strategies based on high resolution accurate mass
- spectrometry for the identification of migrants coming from plastic food packaging
- materials, TrAC Trends Anal. Chem. 110 (2019) 191–203.
- https://doi.org/10.1016/j.trac.2018.10.035.
- [27] M. Onghena, E.V. Hoeck, J.V. Loco, M. Ibáñez, L. Cherta, T. Portolés, E. Pitarch, F. Hernandéz, F. Lemière, A. Covaci, Identification of substances migrating from plastic baby bottles using a combination of low-resolution and high-resolution mass spectrometric analysers coupled to gas and liquid chromatography, J. Mass Spectrom.
- 50 (2015) 1234–1244. https://doi.org/10.1002/jms.3644.
- [28] E.L. Bradley, M. Driffield, J. Guthrie, N. Harmer, P.K.T. Oldring, L. Castle, Analytical approaches to identify potential migrants in polyester–polyurethane can coatings, Food
- Addit. Contam. Part A. 26 (2009) 1602–1610.
- https://doi.org/10.1080/19440040903252256.
- [29] F. Brenz, S. Linke, T.J. Simat, Linear and cyclic oligomers in PET, glycol-modified PET and 526 Tritan[™] used for food contact materials, Food Addit. Contam. Part A. 38 (2020) 160– 179. https://doi.org/10.1080/19440049.2020.1828626.
- [30] E. Pietropaolo, R. Albenga, F. Gosetti, V. Toson, S. Koster, M. Marin-Kuan, J. Veyrand, A. Patin, B. Schilter, A. Pistone, L. Tei, Synthesis, identification and quantification of oligomers from polyester coatings for metal packaging, J. Chromatogr. A. 1578 (2018) 15–27. https://doi.org/10.1016/j.chroma.2018.10.002.
- [31] N. Zhang, G. Kenion, D. Bankmann, S. Mezouari, T.G. Hartman, Migration studies and chemical characterization of low molecular weight cyclic polyester oligomers from food packaging lamination adhesives, Packag. Technol. Sci. 31 (2018) 197–211. https://doi.org/10.1002/pts.2367.
- [32] E. Omer, E. Bichon, S. Hutinet, A.-L. Royer, F. Monteau, H. Germon, P. Hill, G. Remaud, G. Dervilly-Pinel, R. Cariou, B. Le Bizec, Toward the characterisation of non-intentionally added substances migrating from polyester-polyurethane lacquers by comprehensive gas-chromatography-mass spectrometry technologies, J. Chromatogr. A. 1601 (2019) 327–334. https://doi.org/10.1016/j.chroma.2019.05.024.
- [33] H. Hagdrup, H. Egsgaard, L. Carlsen, K.E. Andersen, Contact allergy to 2-hydroxy-5-tert-butyl benzylalcohol and 2,6-bis(hydroxymethyl)-4-tert-butylphenol, components of a phenolic resin used in marking pens, Contact Dermatitis. 31 (1994) 154–156. https://doi.org/10.1111/j.1600-0536.1994.tb01955.x.
- [34] J. Bouajila, G. Raffin, H. Waton, C. Sanglar, J.O. Païsse, M.F. Grenier-Loustalot, Phenolic Resins (II) – Influence of the Chemical Structure of High Molecular Weight Molecules on the Mechanisms of Cross-linking and on the Final Structure of the Resins, Polym. Polym. Compos. 11 (2003) 233–262. https://doi.org/10.1177%2F096739110301100401.
- [35] S.-S. Choi, O.-B. Kim, Y. Kim, Direct analysis of microstructures of alkyl phenol resin using atmospheric pressure chemical ionization-mass spectrometry, Polym. Test. 32 (2013) 366–374. https://doi.org/10.1016/j.polymertesting.2012.11.013.
- [36] E. Zimerson, M. Bruze, Sensitizing Capacity of Two Monomeric Aldehyde Components
- in p- tert -Butylphenol-Formaldehyde Resin, Acta Derm. Venereol. 82 (2002) 418–22. https://doi.org/10.1080/000155502762064539.

Figure 2: Identification protocol of polyester oligomers: case of cyclic EG-PA-EG-PA (EG: ethylene glycol – PA: undefined terephthalic or isophthalic acid)

Figure 3: 70eV(A) and 10eV (B) mass spectra of unknown peak at RT=13.0 min in TbuP formulations

Figure 4: Comparison of mass spectra between A) Unknown peak at RT=13.0 min and B) 4-tert-butyl-2,6-diformylphenol standard

Figure 7: Comparison of phenolic and polyester resin influence on extracted NIAS in GC-MS semi-quantification

571 *Table 1: Identified polyester oligomers in coating extracts*

572

573 *Table 2: Polyester oligomers semi-quantification by GC-MS*

575 *Table 3: Correlation of experimental spectra and attribution on suspected structure*

576

578 *Table 4: Proposed identification of compounds detected in TbuP-based coating extracts and semi-quantification by GC-MS - MOH: methylol group -CH2OH / F:* 579 *formyl group -CHO / HF: Hemiformaldehyde -CH2-O-CH2-OH / bridge: methylene bridge -CH2-*

581 *Table 5: Proposed identification of compounds detected in C-1 coating extracts and semi-quantification by GC-MS*

Retention time	Proposed identification	Proposed formula	Average $(\mu$ g/dm ²)	Monoisotopic mass / mass deviation / RDB	Main fragment / Associated molecular formula / Mass deviation
10.6	C + 2 F	$C_9H_8O_3$	8.7	164.0468 / -0.35 ppm / 6 RDB	163.0389 / $C_9H_7O_3$ / -0.47 ppm
20.7	C -bridge- $C + 2F$	$C_{17}H_{16}O_4$	10.7	284.1043 / -0.11 ppm / 10 RDB	255.1016 / $C_{16}H_{15}O_3$ / 0.15 ppm

