

#### A simple theory helps identifying which different rheological properties can result in the same IDDSI syringe flow test performance

Rémi Lecanu, Cassandre Leverrier, Guy Della Valle, Marco Ramaioli

#### ▶ To cite this version:

Rémi Lecanu, Cassandre Leverrier, Guy Della Valle, Marco Ramaioli. A simple theory helps identifying which different rheological properties can result in the same IDDSI syringe flow test performance. 12th Annual Congres of the European Society for Swallowing Disorders - Deglutology: (re)Connecting in Dysphagia, Sep 2022, Leuven, Belgium. hal-03843429

HAL Id: hal-03843429

https://hal.science/hal-03843429

Submitted on 8 Nov 2022

**HAL** is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers. L'archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d'enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.





# A simple theory helps identifying which different rheological properties can result in the same IDDSI syringe flow test performance

## Rémi LECANU<sup>A</sup>, Cassandre LEVERRIER<sup>A</sup>, Guy DELLA VALLE<sup>B</sup>, Marco RAMAIOLI<sup>A</sup>

<sup>A</sup>Université Paris-Saclay, INRAE, AgroParisTech, UMR 782 SayFood, 91300 Massy & Thiverval-Grignon, France.

<sup>B</sup>INRAE UR 1268, Biopolymers, Interactions & Assemblies (BIA), 44316 Nantes, France.

## Abstract

IDDSI tests<sup>1</sup> are easy to use, inexpensive and widely available thanks to the use of **syringes**, forks and spoons.

The aim of this study is to propose a model to predict the transient flow during the IDDSI syringe flow test. Unlike previous approaches, the simple theory developed in this study does not require the use of any simulation software<sup>3</sup> and predicts IDDSI flow test considering the complete flow curve of the fluid, rather than considering arbitrarily the viscosity at a single shear rate<sup>4</sup>.

This study considers: distilled water and glycerol (N - Newtonian); Vittel water thickened with xanthan gum (XG - Shear thinning); Vittel water thickened with a starch-based commercial thickener, Resource Thicken Up (TU - Shear thinning).

## IDDSI Flow Test and **Rheological Characterisation** Syringe The IDDSI Flow Test is performed **Light Panel** in a syringe recommended by **Camera** IDDSI<sup>2</sup>, and recorded with a camera at 25fps Scale The study considers shear thinning Power-Law fluids: $\eta = K\dot{\gamma}^{n-1}$ K is the consistency index [Pa.s<sup>n</sup>] n is the flow index The fluids are selected to display a large panel of behaviours: 1.00% 6.32% 99% Š 10¹ ⊧ **Shear Rate [1/s] Shear Rate [1/s]** Flow curves of the glycerol (N) and Flow curves of the glycerol (N) and **TU** solutions the XG solutions Glycerol – Newtonian $0.04 \text{ Pa.s} \le \eta \le 1.31 \text{ Pa.s}$





 $0.06 \text{ Pa.s}^{n} \le \mathbf{K} \le 15.8 \text{ Pa.s}^{n} \quad 0.38 \le \mathbf{n} \le 0.75$ Thicken-Up – Range of K and n


#### Final residue after 10s Xanthan gum Thicken-Up **IDDSI Glycerol** concentration concentration Levels concentration

Thickened liquids with very different shear rheology result in the same IDDSI level

## Theoretical Model







## Conclusions

Thickened liquids with very different rheological properties result in the same IDDSI level, using the IDDSI syringe test. The simple theory presented in this study gives a good prediction of the IDDSI Syringe Flow Tests results for Newtonian liquids.

# Perspectives

An extension of this model to more complex rheological properties, can help us identify which different rheological properties can result in the same IDDSI syringe flow test performance and orient future clinical trials to confirm the clinical relevance of this IDDSI "equivalence".

## References

- <sup>1</sup>IDDSI Framework: www.iddsi.org, © The International Dysphagia Diet Standardisation Initiative 2019 @ https://iddsi.org/framework. Licensed under the CreativeCommons Attribution Sharealike 4.0 License https://creativecommons.org/licenses/bysa/4.0/legalcode. Derivative works extending beyond language translation are NOT PERMITTED.
- <sup>2</sup>BDs syringe for IDDSI Flow Test: BD-Syringes-for-IDDSI-Flow-Test-International-Codes.pdf,
- <sup>3</sup>Hanson et al.(2019). *ABE*, 47, 2296-2307.
- <sup>4</sup>Matsuyama et al. (2020). *IJFST 2020*, 55, 2962-2969

### Contact

Rémi Lecanu, remi.lecanu@agroparistech.fr

Marco Ramaioli, marco.ramaioli@inrae.fr

