



Institut National Universitaire **Champollion**

Flat dielectric barrier discharge lamp in interaction with a resonant power supply

B. Caillier¹, D. Florez³, H. Piquet²

¹ Laboratoire Diagnostics des Plasmas Hors Equilibre (DPHE), Université de Toulouse, INU Champollion, Albi, France


² LAPLACE, Université de Toulouse, CNRS, INPT, UPS - Toulouse (France),
³ Universidad Sergio Arboleda, Escuela de Ciencias Exactas e Ingeniería -

Bogota (Colombia)

Introduction

Dielectric Barrier Discharge (DBD) lamps have a lot of applications in industry and research (lighting, surface treatment, etc.), so the knowledge of their behavior and their parameters are essential.

The purpose of this study is to analyze the interaction between a pulsed **current** power supply [2] and a flat DBD lamp [1].



1. B. Caillier, T. Beaudette, L. Therese, P. Belenguer and P. Guillot. (2013), Études et optimisations de lampes planes sans mercure, European Journal of Electrical Engineering 16 565-582.; DOI:10.3166/ejee.16.565-582.


2. David Magin Florez Rubio "Sources d'Alimentation Électrique pour l'Étude et l'Utilisation Efficace des Lampes Excimères DBD", Institut National Polytechnique de Toulouse - INPT, 2014. English. HAL-ID: (tel-00939234)



The DBD lamp is composed of 2 dielectric layers, separated by a gas mixture [1].

Dielectric thickness : 3.15mm GAP : 2 mm Gas : Ne-Xe 50% 400 mBar Area : 60x60 cm


Plasma will appear in the gap when the vGas voltage reaches the Vth threshold.





Circuit

The Power Supply operates on a resonance principle





power source = fixed part of the power supply + coil to be adapted


Electrical transformer = part to be adapted Dielectric barrier discharge part = Characteristics to be determined




Manley Diagram







AB and CD: capacitive phases plasma off. The slope of AB indicates the capacity value Céq.




BC and DA: discharge phases plasma on. The slope of BC indicates the capacity value Cd.

C=Cd



From Measurements



Time (s)


From electric measurements and a Matlab program, capacity Cd, Cg and Vth could be deduced


Cd=1.70E-9 F Cg=2.17E-9 F Vth=430 V



Pspice's simulations

Cd=1.70E-9 F Cg=2.17E-9 F






Experimental Current


With Pspice, the previous calculated capacities (Cd and Cg) and the experimental current, the voltage could be simulated and compared to the experimental one.


Results : Frequencies



20kHz to 80kHz

Series of measurements by setting the input voltage amplitude to 150V and varying the frequency from 20kHz to 80kHz











Obtained from DBD model

Capacitance













Power + Luminance measurements = Efficiency



Frequency impact





- Theoretical formulas make it possible to determine in advance the voltage, current and power amplitudes.
- Maximum efficiency of 18 lum/Watts achieved.
- An additional optical study will have to be carried out by modifying the inductance value



- Theoretical formulas make it possible to determine in advance the voltage, current and power amplitudes.
- Maximum efficiency of 18 lum/Watts achieved.
- An additional optical study will have to be carried out by modifying the inductance value

