

Molecular beam epitaxy of III-V semiconductors on group-IV substrates: Formation and burying of antiphase domains.

A. Gilbert¹, J.-B. Rodriguez¹, M. Rio Calvo¹, M. Ramonda¹, L. Cerutti¹,
C. Cornet², A. Trampert³, G. Patriarche⁴, E. Tournié¹

¹: IES, University of Montpellier, CNRS, F- 34000 Montpellier, France


²: Univ Rennes, INSA Rennes, CNRS, Institut FOTON – UMR 6082, F-35000 Rennes,

³: Paul-Drude-Institut für Festkörperphysik, Hausvogteiplatz 5-7, 10117 Berlin, Germany


⁴ : C2N, University of Paris Sud, CNRS, UMR 9001, Paris, France

This work is supported by the French program Equipex EXTRA (ANR11-EQPX-0016) and by the ANR- DFG project FILTER (ANR-20-CE92-0045).

Motivations




Motivations



Material quality

Substrate preparation



Twins
Solved

Lattice mismatch

Dislocations
Non radiative recombination
centers



Polarity mismatch

APBs
Short cuts

APBs kill devices


Antiphase boundaries (APBs)

Zinc Blend is polar (two types of atoms)




Diamond is non-polar (one atom)

Antiphase boundaries (APBs)





The two phases grow and nucleate




Burying mechanism model

III-polar phase APB V-polar phase





III-V steps in one direction



Different incorporation rates = the domain that grows slower is buried


Experimental demonstration of the model: GaSb on Si 0.5°






GaAs on 0.5° Si: growth and characterizations

Surface morphology of GaAs low temperature growths





Surface covered with parallel elongated structures

Hypothesis: regular succession of APD-MPD
dark trenches = APBs




TEM confirms APD-MPD sequence and MPD overgrowth



Regular repetition **APD-MPD** (dark-clear regions)
MPD grows faster


Periodic repetition




GaAs periodic distribution of APD-MPD

25 nm GaAs

Si 0.5°



Repetition size is determined by AFM




Average periodicity on $2\mu\text{m} \times 2\mu\text{m}$ AFM of 25 nm GaAs


=

31.7 nm




Si 0.5° mono-atomic terraces width determination



$a_{Si} = 0.54 \text{ nm (300 K)}$
Mono-atomic steps height = $a_{Si} / 4$
Terrace width $L = a_{Si} / (4 \times \tan(\theta))$




Si 0.5° mono-atomic terraces width determination





1 domain width = 1 Si terrace width

Determination of period width with 0.2° miscut






Average periodicity on 2 μ m x 2 μ m AFM = **82 nm**



1 domain on 1 Si terrace

Islands organization for 50 nm GaAs on 0.2° Si




Perpendicular domains
1 phase on 1 Si mono-atomic terrace

=


Initial 3D islands are smaller than Si terraces

Regime transition

Terrace-driven $W < L$



Nucleation-driven $W > L$






Temperature rise = regime transition





Growth conditions influence on stable island size




Temperature dependent evolution of the stable island size






Temperature dependent evolution of the stable island size



Temperature dependent evolution of the stable island size






Temperature dependent evolution of the stable island size



Disorganization of surface
Size of island > Si terrace width


Temperature dependent evolution of the stable island size



Disorganization of surface
Size of island > Si terrace width

Conclusion


Burying mechanism demonstrated for GaAs on Si



500 nm GaAs APBs-free layers


GaAs terrace driven regime

350°C




nucleation driven

520°C



Next: Validation of APDs burying model for other III-Vs and alloys on group IV substrates

Use these APB-free samples as templates to grow devices



Thank you for your attention