

Design of innovative diamond detectors for beam monitoring in highly radiative environment for applications in nuclear and medical physics

M.-L. Gallin-Martel, J.-L. Bouly, J. Collot, D. Dauvergne, P. Everaere, L. Gallin-Martel, C. Hoarau, F. Lafont, E. Lagorio, S. Marcatili, et al.

▶ To cite this version:

M.-L. Gallin-Martel, J.-L. Bouly, J. Collot, D. Dauvergne, P. Everaere, et al.. Design of innovative diamond detectors for beam monitoring in highly radiative environment for applications in nuclear and medical physics. MRS 2023 Spring Meeting, May 2023, Strasbourg, France. hal-04694008

HAL Id: hal-04694008

https://hal.science/hal-04694008

Submitted on 11 Sep 2024

HAL is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers. L'archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d'enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.



Design of innovative diamond detectors for beam monitoring in highly radiative environment for applications in nuclear and medical physics



M.-L. Gallin-Martel*, J.-L. Bouly, J. Collot, D. Dauvergne, P. Everaere, L. Gallin-Martel, C. Hoarau,

F. Lafont, E. Lagorio, S. Marcatili, R. Molle, J.-F. Muraz, N. Ponchant, F. Rarbi, M. Reynaud, O. Rossetto, J. Waquet, M. Yamouni



A. Guertin, F. Haddad, C. Koumeir,



V. Métivier, R. Molle, F. Poirier, N. Servagent



L. Abbassi, T. Crozes, J.-F. Motte



F. Lafont, T-N Tran - Thi













*mlgallin@lpsc.in2p3.fr


Context

- > Development of new generations of ion accelerators:
 - medical applications: hadrontherapy, flash therapies and X-ray or synchrotron radiation therapy
 - ⇒ very precise monitoring of the beam with rapid counting in a highly radiative environment.
- > The intrinsic qualities of diamond:
 - speed, low leakage current, excellent SNR, resistance to radiation
 - \Rightarrow an excellent candidate to meet such monitoring requirements over a wide dynamic range from a fraction of pA (single particle) up to μ A.


Context


- > Development of new generations of ion accelerators:
 - medical applications: hadrontherapy, flash therapies and X-ray or synchrotron radiation therapy
 - ⇒ very precise monitoring of the beam with rapid counting in a highly radiative environment.
- > The intrinsic qualities of diamond:
 - speed, low leakage current, excellent SNR, resistance to radiation
 - \Rightarrow an excellent candidate to meet such monitoring requirements over a wide dynamic range from a fraction of pA (single particle) up to μ A.

What is hadrontherapy in cancer treatment?




Hadrontherapy in cancer treatment






> Energy deposition at the end of ion path in the Bragg peak = dose deposition (Gy) very locally in the tumor volume

Towards Flash therapies in cancer treatment: the new challenges for beam monitoring!




Flash therapy vs conventionnal = high doses in a very short time

- ⇒ Short pulses to be monitored at **high beam intensity**!
- ⇒ **High particle couting rate capabilities** to be demonstrated
- ⇒ Bunch or train of bunches time stamps



Towards Flash therapies in cancer treatment: the new challenges for beam monitoring!



Flash therapy vs conventionnal = high doses in a very short time

- ⇒ Short pulses to be monitored at **high beam intensity**!
- ⇒ **High particle couting rate capabilities** to be demonstrated
- ⇒ Bunch or train of bunches time stamps




Solid state ionization chamber

Diamond Assets:

- ☐ Intrinsic radiation hardness
- ☐ Fast signal risetime enables timing precision of a few tens of ps
- Low noise

Issues:

- **☐** Cost
- Availability of large area




Solid state ionization chamber


Diamond Assets:

- ☐ Intrinsic radiation hardness
- ☐ Fast signal risetime enables timing precision of a few tens of ps
- Low noise

Issues:

- **☐** Cost
- Availability of large area






Solid state ionization chamber

Diamond Assets:

- ☐ Intrinsic radiation hardness
- ☐ Fast signal risetime enables timing precision of a few tens of ps
- Low noise

Issues:


- ☐ Cost
- ☐ Availability of large area




Diamond metallisation









Detector assembly















Solid state ionization chamber

Diamond Assets:

- Intrinsic radiation hardness
- Fast signal risetime enables timing precision of a few tens of ps
- Low noise

Issues:

- **☐** Cost
- Availability of large area




Read-out electronics

- Fast current preamplifier
- Charge preamplifier
- Electrometer


Diamond metallisation










Detector assembly














Solid state ionization chamber

Diamond Assets:

- Intrinsic radiation hardness
- Fast signal risetime enables timing precision of a few tens of ps
- Low noise

Issues:


- Cost
- Availability of large area




Diamond metallisation









Detector assembly














Read-out electronics

- Fast current preamplifier
- Charge preamplifier
- Electrometer



Band Width: 2 GHz

40 dB Gain:

Impedance: 50 Ω

~ +/- 1 V **Dynamic range:**

12 V / 100 mA **Power Supply:**


Solid state ionization chamber

Diamond Assets:

- Intrinsic radiation hardness
- Fast signal risetime enables timing precision of a few tens of ps
- Low noise

Issues:


- Cost
- Availability of large area




Diamond metallisation









Detector assembly















Read-out electronics

- Fast current preamplifier
- Charge preamplifier
- Electrometer

Read out electronics @ LPSC



Discret





C. Hoarau et al 2021 JINST 16 T04005

https://doi.org/10.1088/1748-0221/16/04/T04005


Solid state ionization chamber

Diamond Assets:

- Intrinsic radiation hardness
- Fast signal risetime enables timing precision of a few tens of ps
- Low noise

Issues:


- ☐ Cost
- Availability of large area




Diamond metallisation









Detector assembly
















Read-out electronics

- Fast current preamplifier
- Charge preamplifier
- Electrometer

Read out electronics @ LPSC









C. Hoarau *et al* 2021 *JINST* **16** T04005

https://doi.org/10.1088/1748-0221/16/04/T04005


Diamond detector for beam monitoring: sCVD? pCVD? DOI?







Diamond detector for beam monitoring: sCVD? pCVD? DOI?










XBIC = X rays Beam Induced Current


@ ESRF (France) : Photons 8.5 keV


May 29 - June 2

Diamond detector for beam monitoring: sCVD? pCVD? DOI?













XBIC = X rays Beam Induced Current


@ ESRF (France) : Photons 8.5 keV=> 2D « current maps » with CVD diamonds














1 mm²

ML Gallin-Martel Diamond and related materials 112 (2021) 108236

https://doi.org/10.1016/j.diamond.2020.108236


ARRONAX in Nantes (France) ARRONAX





- 68 MeV proton / 70 MeV alpha particles cyclotron
- Beam intensity up to 20μA
- Continuous or pulse mode beam delivery with tunable dt and dit time duration
- Bunch : 4ns ON, 29ns OFF (f = 30,45 MHz)






Source: The pulsing chopper-based system of the ARRONAX C70XP Cyclotron, Poirier et al., International Particle Accelerator Conference, 2019. URL


https://doi.org/10.18429/JACoW-IPAC2019-TUPTS008

Beam test set-up in ARRONAX with 68 MeV proton beams





Diamond set-up










DIAMMONI – Train counting and time stamps at high beam intensity





Train Counting Mode

Beam intensity up to 300 nA measured on diamond



I = 10nA, dt = 10μs, dit = 1s


QDC board developped @ LPSC

DAQ developped @ LPSC R. Molle
PhD Thesis
LPSC ARRONAX SUBATECH


DSO Lecroy 2 GHz; 10 or 20 GS/s




Train - Diamond signal



Train integral = DSO post analysis



Train integral = on line measurement with LPSC QDC






DIAMMONI – Train counting and time stamps at high beam intensity






Study of linearity as a function of beam intensity







DIAMMONI equipped with:

150 µm thick sCVD diamonds mounted on PCB



+ DAQ









for monitoring proton beams in FLASH conditions




DIAMMONI – Diamond signal analysis and simulation







150 μm sCVD diamond signal for different beam intensities (amplitude normalized)





Simulation with a gaseous ionisation chamber



PyDiam simulation package in Python 3 R. Molle PhD thesis









DIAMMONI – Diamond aging studies : strategy with flux and fluence






Objectives of the "aging" experimental set-up:

- \triangleright each area corresponds to a beam intensity (= flux = φ)
- \succ Irradiation of each zone until obtaining an identical cumulative fluence (= ϕ) between the zones at the end of the experiment


Before irradiation

sCVD 500μm E6





XBIC mapping at ESRF



Targeting objective



DIAMMONI – Diamond aging studies : XBIC maps at ESRF on BM05



After

irradiation



See session M04, talk 526 F. Lafont

This diamond was irradiated with 68-MeV alpha particles at ARRONAX with a fluence of approximately 10¹⁵ ions/cm²

The absolute values cannot be compared since the beam intensity is not the same


The current scales are in relation to the X-beam intensities in the two experiments (before vs after irradiation)

=> The main observation is that the XBIC is close to the leakage current in the irradiated areas which means that the charges are no


longer collected.



sCVD 500µm E6



XBIC mapping at ESRF



In blue the areas of less effective

charge collection

To understand if the origin if this degradation, Bragg diffraction imaging was performed.

No irradiation-related structural defects are visible => the vacancies created by the irradiation are too far from one another to induce a significant deformation of the crystalline mesh.


From simple calculations, we estimated the displacements per atom to be of the order of few p.p.m

DIAMMONI – Diamond aging studies: impact of the flux on CCE






Impact of flux on charge collection efficiency







Charge normalized by alpha particle

With increasing flux, charge collection decreases.

The fluence creates damage in the detector.

→ It results in the creation of traps that disrupt the collection of charges.

Possibly reversible phenomenon: annealing?

Annealing studies are on going! Results soon ...

Conclusion

- > The development are in connection with collaborations established at CNRS and ESRF
- > It has been done in the context of interdisciplinary research IN2P3 INP skills exchanges take place between
 - characterization: sources (labs) + accelerator beams @ IN2P3 GIP ARRONAX, XBIC @ ESRF +...
 - Instrumentation (IN2P3 labs, Institut Néel, etc.)
- > A diamond beam monitor + FE electronics and DAQ has been developed in the context of ANR-DIAMMONI:
 - it satisfies beam monitoring in the FLASH therapy condition (linear response in the range 1 to 4 10⁵ Gy/s)
 - the proposed detection systems will bring significant added value to the transfer of high dose rate flash radiotherapy to clinical trials
- ➤ Aging studies are on going for a better understanding of the impact of very high fluences (up to 10¹⁵ ions/cm²) on charge collection











THANKS FOR YOUR ATTENTION!











