

High-performance gyroscope for rotational seismology.

Arnaud Landragin, Mohamed Guessoum, Remi Geiger, Nathan Marliere

▶ To cite this version:

Arnaud Landragin, Mohamed Guessoum, Remi Geiger, Nathan Marliere. High-performance gyroscope for rotational seismology.. Frontiers of Matterwave Optics 2024, Sep 2024, Kolimpari, Chania, Crete, Croatia. hal-04749914

HAL Id: hal-04749914 https://hal.science/hal-04749914v1

Submitted on 23 Oct 2024

HAL is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers. L'archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d'enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.



SYstèmes de Référence Temps-Espace







High-performance gyroscope for rotational seismology.

Nathan Marliere, Mohamed Guessoum,

Remi Geiger et Arnaud Landragin



INTRODUCTION



Presentation of cold atom sensors

IACI: Atomic interferometry and Inertial Sensors

An inertial sensor measures accelerations or rotations of an object in an inertial frame

Ex: Gravimeters, gradiometers, gyroscopes...

Various fields of applications





INTRODUCTION

Atomic gyroscopes Vs Optical gyroscopes

Sagnac effect: phase proportional to rotation at the output of an interferometer



$$\Delta \Phi_{\Omega} = \frac{4\pi E}{hc^2} \vec{A}. \vec{\Omega}$$

E: Energy of the particle used

A: Area of the interferometer

Quick comparison Atoms/Optics :

	Energy	Area	Shot noise (sensitivity ∕√N)
Photons	~1 eV	In the order of m ²	10 ¹⁵ Photons/s/mW
Atoms (Cs)	~10 ¹¹ eV 🕃	mm ² to cm ² (This work: 11cm ²) 这	10 ⁷ Atoms/s 这





State of the art of Gyroscopes

Fiber optics gyroscope



iXBlue FOG

Sensitivity: 6.10⁻⁸ rad.s⁻¹.Hz^{-1/2} Stability: 4.10⁻¹⁰ rad.s⁻¹ (8 Days)

Gyrolaser G-Ring



G-Ring, 16 m² Sensitivity: **1.2x10⁻¹¹ rad.s⁻¹.Hz^{-1/2}** Stability: **7x10⁻¹³ rad.s⁻¹ (2 h)** Cold atom gyroscope (This work)

Sensitivity: $3 \times 10^{-8} rad. s^{-1}. Hz^{-1/2}$ Stability: $2 \times 10^{-10} rad. s^{-1}$ (8h)



ATOMIC INTERFEROMETRY SYRTE Deservatoire | PSL S SORBONNE

4-pulse interferometer: Gyroscope





SYRTE Observatoire | PSL 🕱 SORBONNE

Vibration noise sources





EXPERIMENTAL SET-UP

SYRTE Observatoire | PSL Sorbonne





SYRTE Observatoire | PSL



Vibration noise



Vibration noise covers several rad



Attenuates high frequencies above 0.5 Hz



SYRTE Doservatoire | PSL 🔀 🗳 SORBONNE de Paris

Vibration noise correlation



 $\Delta \Phi_{\rm tot} = \Phi_{\Omega} + \delta \Phi_{\rm vib} + \delta \Phi_{laser}$

Vibration noise covers several rad



Correlation with classical sensors





SYRTE Observatoire | PSL SORBONNE

Compensation of vibrations

Compensating vibrations using the laser phase



$$P = \frac{1}{2} \left(1 + C \sin\left(\Phi_{\Omega} + \Phi_{\text{vib}} + \Phi_{\text{compensation}} + \Phi_{laser}\right) + \delta\phi_{residue} < 1 \right)$$



Gyroscope operation sequence

Sequential operation of cold atom interferometers:



Dead times — Prevents from reaching the quantum noise limit.

Meunier, PRA (2014) Jekeli, Navigation 52, 1 (2005)

Cancelling dead times with other operating methods



Dead Times with no-joint mode







Simple-Joint Mode





Stability record - triple-joint sequence

Triple-Joint Interrogation:

Faster averaging of rotations (N^{-1}) visible due to a better estimation of noise





Double-Joint Mode





The double-diffraction



Main advantages:

Enable the Double-joint mode

- Enhance sensitivity by doubling interferometric area
- Rejection of systematic effects

Double Diffraction —> Laser phase not available to scan fringes —> Develop new methods to scan the phase



New techniques to scan the interferometric phase



Implementation of Mirror jumps



Characterization of the step response



Characterization of the Scale factor





~426 $nm/360^{\circ}$ on $\pi/_2$ pulse (Divided by 2 in double diffraction)



Implementation of Frequency jumps

Precise measurement on L







~ 370 *MHz*/180° on $\pi/_2$ pulse (Divided by 2 in double diffraction)





Comparison of results obtained for each methods







Conclusion

▶ New methods for RTC **demonstrated** in simple diffraction to enable **Double-Diffraction**

- Implementation of **Double-Diffraction**:
 - Cancelling systematic effects
 - > **Double** interferometer area
 - Enable Double-Joint sequence
 - > Space applications
- Implementation and test of Double-Joint:
 - Faster averaging of vibrations
 - Rotational seismology Applications



SYstèmes de Référence Temps-Espace







Thanks for your attention