

# Deciphering the dynamics of galvanic replacement reaction to design metallic cages as free-standing electrocatalysts

Amira Ben Abderrahmane, Sophie Tingry, David Cornu, Yaovi Holade

## ► To cite this version:

Amira Ben Abderrahmane, Sophie Tingry, David Cornu, Yaovi Holade. Deciphering the dynamics of galvanic replacement reaction to design metallic cages as free-standing electrocatalysts. SCF 2023, Jun 2023, Nantes, France. hal-04797970

## HAL Id: hal-04797970 https://hal.science/hal-04797970v1

Submitted on 22 Nov 2024

**HAL** is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers. L'archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d'enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.



Distributed under a Creative Commons Attribution 4.0 International License

### DECIPHERING THE DYNAMICS OF GALVANIC REPLACEMENT REACTION TO DESIGN METALLIC CAGES AS FREE-STANDING ELECTROCATALYSTS

Amira BEN ABDERRAHMANE, Sophie TINGRY, David CORNU and Yaovi HOLADE

Institut Europeen des Membranes, IEM UMR 5635, Univ Montpellier, ENSCM, CNRS, Montpellier, France yaovi.holade@enscm.fr; https://iem.umontpellier.fr/


Keywords: Galvanic replacement reaction; Electrochemistry; Gold; Silver; Nanostructured interface

#### Summary:

Galvanic replacement reaction (GRR) occurs spontaneously when the atoms of one metal are in contact with the ions of another metal that has a higher redox potential in solution. Owing to its versatility, GRR has far-reaching technological implications beyond physical chemistry in catalysis, chemistry, physics, biology, and medicine.<sup>[1,2]</sup>

In the bulk state, silver with  $E^{\circ}(Ag^{+}/Ag) = 0.8 \text{ V vs SHE}$  (standard hydrogen electrode) can be replaced by gold with  $E^{\circ}(AuCl_{4^{-}}/Au) = 1.0 \text{ V vs SHE}$  according to:  $3Ag_{(s)} + AuCl_{4^{-}(aq)} \rightarrow 3Ag^{+}_{(aq)} + 4Cl^{-} + Au_{(s)}$ . Given that the introduction of 1 atom of Au requires the replacement of 3 atoms of Ag (Ag and Au atoms have similar size), GRR generates porous and alloyed structures with unique physicochemical properties.<sup>[1-3]</sup> Fundamentally, the exact driving force is quantitatively unknown as from a physical chemistry point of view, the understanding of the dynamics of such a redox process, which mixes electrochemical kinetics and mass transport (diffusion), remains a puzzle. Historically, both the synthesis of the initial Ag particles and the GRR are done in solution, making electroanalytical monitoring impossible.

We will discuss our recent methodology allowing to grow surfactant-free Ag particles on GDE and then perform GRR with Au while monitoring the dynamics via the open circuit potential (OCP, **Fig. 1a**).<sup>[3]</sup> It allows to capture in real time the formation of metallic cages of Ag-Au alloys after a '3by1' atomic exchange. This strategy has led to the fabrication of high performance electrocatalysts where the formation of an alloy phase, the creation of nanoporosity within it and the self-supporting nature amplify, through synergistic and electronic effects, the electrocatalytic activity (**Fig. 1b**).<sup>[1]</sup>



**Fig. 1.** (a) Open circuit potential (OCP) during GRR (3.5 M NaCl, rt, gentle stirring): inset shows SEM images of the initial GDE-Ag and final GRR-Au<sub>90</sub>Ag<sub>10</sub> electrodes. (b) Comparative performance (CVs at 50 mV s<sup>-1</sup> in 1 M KOH+0.1 M glycerol at 25 °C).

References:

1. Jang, H.; Min, D.-H., ACS Nano. 2015, 9 (3), 2696-2703.

2. Liu, X.; Astruc, D., Adv. Mater. 2017, 29 (16), 1605305.

3. Boukil, R.; Tuleushova, N.; Cot, D.; Rebiere, B.; Bonniol, V.; Cambedouzou, J.; Tingry, S.; Cornu, D.; Holade, Y., *J. Mater. Chem. A.* **2020**, 8 (18), 8848-8856