Supplementary information

Figure S.I.14: [Rietveld refinements for H2-D2 \(a\) and NH3-P28 \(b\) calculated with](#page-15-0) MAUD. In the first case, the R_{wp} is 7.99% and in the second, it is 6.81%. The black dots are [the XRD measurements and the red line is the refinement. The black line below represents the](#page-15-0) [difference between the experiment and the refinement...16](#page-15-0)

A.Ammonia reduction

Ammonia reduction pathways according to the temperature [1,2]:

• 430 °C – 530 °C: Direct reduction by ammonia:

$$
\frac{1}{2} Fe_2O_3 + \frac{1}{9} NH_3 \rightarrow \frac{1}{3} Fe_3O_4 + \frac{1}{18} N_2 + \frac{1}{6} H_2O
$$
 S.I.1

$$
Fe_3O_4 + 2NH_3 \to 3Fe + N_2 + 4H_2O
$$
 S.I.2

• Over 530 °C: Indirect reduction via decomposition of ammonia [3]:

$$
2 NH_3 \rightarrow N_2 + 3 H_2
$$
 S.I.3

• Below °C:

$$
3 Fe2O3 + H2 \to 2 Fe3O4 + H2O
$$
 S.I.4

$$
Fe_3O_4 + 4H_2 \to 3Fe + 4H_2O
$$
 S.I.5

• Over 570 °C:

$$
3 Fe_2O_3 + H_2 \to 2 Fe_3O_4 + H_2O
$$
 S.I.6

$$
Fe_3O_4 + H_2 \rightarrow 3\,FeO + H_2O
$$
 S.I.7

$$
FeO + H_2 \rightarrow Fe + H_2O
$$
 S.I.8

• Over 450 °C: Nitriding:

$$
\frac{8}{11} Fe_3O_4 + 2 NH_3 \rightarrow \frac{6}{11} Fe_4N + \frac{6}{11} H_2 + \frac{8}{11} N_2 + \frac{32}{11} H_2O
$$
 S.I.9

$$
y Fe + NH_3 \rightarrow Fe_y N + \frac{3}{2} H_2
$$
 S.I.1
0

• Nitride decomposition:

$$
FeyN \rightarrow y Fe + \frac{1}{2} N_2
$$
 S.I.1
1

B.Experimental setup

Table S.I.1: *Rietveld refinement on XRD analysis of a powdered industrial hematite pellet* $(R_{wp} = 9.858\%).$

Figure S.I.1: *Schematic of the experimental set-up*

Figure S.I.2: *Pictures of the sample holders used for the reductions under concentrated light flux. a) Crucible used for the pellets and b) crucible used for the disks.*

Figure S.I.3: Flux received by the top of the crucible. The maximum of 115 W_l/cm^2 is *reached at the center and the average is 75 Wl/cm² . On the crucible aperture area, a power of about 150 W^l is measured (grey area of the blue curve).*

C. Influence of temperature

Diffractograms of **Part. III.1.** are presented below.

Figure S.I.4: *XRD analysis at different times of industrial hematite powder heated at 400 °C under 5%-NH³ atmosphere. The first scan is taken before heating and the second starts when the setpoint temperature is reached.*

Figure S.I.5: *XRD analysis at different times of industrial hematite powder heated at 450 °C under 5%-NH³ atmosphere. The first scan is taken before heating and the second starts when the setpoint temperature is reached.*

Figure S.I.6: *XRD analysis at different times of industrial hematite powder heated at 500 °C under 5%-NH³ atmosphere. The first scan is taken before heating and the second starts when the setpoint temperature is reached.*

Figure S.I.7: *XRD analysis at different times of industrial hematite powder heated at 550 °C under 5%-NH³ atmosphere. The first scan is taken before heating and the second starts when the setpoint temperature is reached.*

Figure S.I.8: *XRD analysis at different times of industrial hematite powder heated at 600 °C under 5%-NH³ atmosphere. The first scan is taken before heating and the second starts when the setpoint temperature is reached.*

D.Temperature and gas composition measurements

Figure S.I.9: *a) Picture of the perforated crucible used to measure the temperature at the bottom of the samples during reduction using a type K thermocouple. b) Picture of the experimental setup used to measure the temperature at the top of the samples during reduction.* A type K thermocouple in contact with the top of the pellet is visible.

Figure S.I.10: *Temperatures measured at the top (straight lines) and at the botton (dashed lines) of pellets exposed 28 min to the light flux under hydrogen (green) or ammonia (red) atmosphere.*

Figure S.I.11: *NH3/H² ratio measured by mass spectrometry during the reduction by ammonia of a pellet sample exposed for 28 min to the luminous flux.*

E. Comparison with hydrogen-based reduction for different samples

Table S.I.2: *Detail of the degrees of reduction (DoR) and degrees of metallization (DoM) of the samples reduced by hydrogen and ammonia. For the pellets, about 90% of the grinded sample was analysed by XRD. For the disks, two scans per sample were conducted with about 20% of the powder per batch resulting in two DoR and two DoM per sample; the mean value was calculated for each sample.*

Diffractograms of samples studied in **Part III.2.** are presented below.

Figure S.I.12: *XRD analysis of the samples reduced for different times under H² or NH3.*

F. Reduction by ammonia of disk samples

Figure S.I.13: *XRD analysis of the disk samples reduced for different times under NH3.*

Figure S.I.14: *Rietveld refinements for H2-D2 (a) and NH3-P28 (b) calculated with MAUD. In the first case, the Rwp is 7.99% and in the second, it is 6.81%. The black dots are the XRD measurements and the red line is the refinement. The black line below represents the difference between the experiment and the refinement.*

G.Energy necessary to produce the reducers

Hydrogen

- Via electrolysis, around 52 kWh are needed to produce 1 kg of H_2 [4]
- According to the reduction equation: $Fe_2O_3 + 3 H_2 \rightarrow 2 Fe + 3 H_2O$, $\frac{3}{2}$ $\frac{3}{2}$ mol of H₂ are needed to produce 1 mol of Fe.
- Using the molar masses of H₂ (2 g/mol) and of Fe (55.8 g/mol), one deduces that: 1 t of Fe (17920 mol of Fe) requires 26882 mol of H_2 (54 kg of H_2) to be produced, corresponding to 2808 kWh/t of iron.
- In 2021, 1951 Mt of steel were produced [5], so 5478 TWh of electricity would be needed to produce the necessary hydrogen to decarbonize the process.
- The global electricity production of 2021 is 28000 TWh, so 19.5% of the global electricity production should be dedicated to the production of the hydrogen required to produce iron.

Ammonia

- Via electrolysis and Haber-Bosh, 0.177 kg of H_2 are needed to produce 1 kg of NH₃ [6] *i.e*. 9.2 kWh.
- The production of hydrogen represents around 80% of the energy needed to produce ammonia [4], which means that 11.5 kWh are needed in total to produce 1 kg of NH3.
- 2 $\frac{2}{3}$ mol of NH₃ are needed to produce 1 mol of H₂.
- With the molar masses of NH₃ (17 g/mol), H₂ (2 g/mol) and of Fe (55.8 g/mol), one deduces that:

1 t of Fe requires 17920 mol of $NH₃(305 kg of NH₃)$ to be produced, corresponding to around 3510 kWh/t of iron.

• 6848 TWh of electricity would be needed to produce the ammonia necessary to decarbonize 2021 steel production, corresponding to 24.5% of the global electricity production.

One should note that these calculations depend on the exact numbers chosen for the electricity needed to produce 1 kg of hydrogen or ammonia and that values slightly vary depending on sources. We took the most coherent values and/or averages. These calculations aim at providing orders of magnitude, which are in principle correct.

References

- [1] S. Hosokai, Y. Kasiwaya, K. Matsui, N. Okinaka, and T. Akiyama, Ironmaking with Ammonia at Low Temperature, Environ. Sci. Technol. 45, 821 (2011).
- [2] N. Yasuda, Y. Mochizuki, N. Tsubouchi, and T. Akiyama, Reduction and Nitriding Behavior of Hematite with Ammonia, ISIJ Int. 55, 736 (2015).
- [3] A. Ranzani Da Costa, La Réduction Du Minerai de Fer Par l'hydrogène : Étude Cinétique, Phénomène de Collage et Modélisation, Institut National Polytechnique de Laurraine, 2011.
- [4] The Future of Hydrogen, International Energy Agency (2019)
- [5] *World Steel in Figures 2022*, https://worldsteel.org/steel-topics/statistics/world-steel-infigures-2022/.
- [6] Y. Bicer and I. Dincer, Life cycle assessment of nuclear-based hydrogen and ammonia production options: A comparative evaluation, Int. J. Hydrog. Energy 42, 21559 (2017).